

Anybus X-gateway CANopen - Modbus RTU INSTALLATION SHEET




HMS Industrial Networks AB
Web: www.anybus.com
Tel: +46 35 172900
E-mail: info@hms.se




SP1195, rev 2.00, Apr 2012. AB7305.

www.anybus.com

Module Front



Modbus RTU Connector



Pin no	Name	Function
2	RS232 - Tx	Transmit signal
3	RS232 - Rx	Receive signal
5	GND	Signal ground
6	+5 V	Power supply
7	RS485 D0	
8	RS485 D1	
Casing	PE	
1, 4, 9	-	(not connected)

LED Indicators

LED no	Indication	Meaning
1 (Bus Error)	Off	Normal operation
	Red	Bus Error
2 (Bus Ready)	Off	No power
	Green	Bus ready
	Red	Bus timeout error
3 (Processing)	Off	No query is currently being processed
	Flashing green	Processing query
4 (HW Settings Status)	Off	Using switch settings, normal operation
	Red	Not configured. Operating at 19200 bps. Will only respond to broadcast messages.
5 (CANopen Subnet Status) ¹	Off	Power off
	Flickering green/red	The LSS services are in progress
	Blinking green	Pre-operational state
	Single flash, green	Stopped state
	Green	Operational state
	Blinking red	Configuration error
	Single flash, red	Warning limit reached
	Double flash, red	Error control event
	Triple flash, red	Sync error
	Quadruple flash, red	Data communication timeout
Red	Bus off	
6 (Device Status)	Off	Power off
	Single flash, green	Startup
	Green	Running
	Single flash, red	Initialization error
	Double flash, red	Timeout
	Triple flash, red	Hardware failure
	Quadruple flash, red	General error
	Red	Fatal error

1. This LED shows the status of the CANopen subnet that is controlled by the X-Gateway CANopen.

Accessories Checklist

The following items are required for installation:

CANopen:

- CANopen configuration tool (available at www.anybus.com)
- CANopen adapter for configuration tool (not included)
- CANopen cable (not included)
- EDS file, available at www.anybus.com

Modbus RTU Interface:

- Modbus RTU cable (not included)
- Configuration tool (not included)


Installation and Startup Summary

- Select baud rate and an unused node address for the interface. (Cover the switches with the enclosed switch covers.)
- Connect the gateway to the CANopen network.
- Install the EDS file in the CANopen configuration tool.
- Power up and (if required) configure the module.
- Restart the module after the CANopen interface has been configured.
- Connect the gateway to the Modbus RTU network.
- Set baud rate etc. using the switches.
- Power up and (if required) configure the module.

Please note that the module will start up as a CANopen slave. The module can be reconfigured as a CANopen master during configuration.

Side View

Setting	Baud Rate (kbit/s)
0	20
1	50
2	125
3	250
4	500
5	800
6	1000
7	Auto
8, 9	Not available



Allowed node address range is 1 - 127. Addresses 1 - 99 are available using the address rotary switches. To set e.g. node address 42, set the left address switch to 4 and the right address switch to 2. Cover the switches with the enclosed switch covers to ensure EMC compliance.

Modbus RTU Switch Settings

The Node Address is set in binary form with switches 1 - 7. Each module has to have a unique address.


The rest of the switches are used as shown in the tables below.

Baud Rate (Bps)	Sw. 8	Sw. 1	Sw. 2
-	OFF	OFF	OFF
1200	OFF	OFF	ON
2400	OFF	ON	OFF
4800	OFF	ON	ON
9600	ON	OFF	OFF
19200	ON	OFF	ON
38400	ON	ON	OFF
57600	ON	ON	ON

Parity	Stop Bits	Sw. 3	Sw. 4
-	-	OFF	OFF
None (default)	2	OFF	ON
Even	1	ON	OFF
Odd	1	ON	ON

Physical Interface	Sw. 5
RS232	ON
RS485	OFF

Bottom View



USB port:
Connect a PC to the USB port for firm-ware upgrades.

Power:
A. +24 V DC
B. GND

CANopen Connector

Pin no.	Description
2	CAN_L
5	Shield
7	CAN_H
3, 6	CAN_GND
1, 4, 8, 9	(not connected)

Technical Details

- Power supply:
24 V DC (-10% to +10%).
- Power consumption:
Maximum power consumption is 250 mA @ 24 V DC.
Typical power consumption: 100 mA @ 24 V DC.
- Protective Earth (PE):
Internal connection to PE via DIN-rail.
Note: Make sure the DIN-rail is properly connected to PE.

CANopen Support

Technical support regarding the CANopen fieldbus system should be addressed to CAN in Automation (CiA).
Online: www.can-cia.org

Modbus RTU Support


Technical questions regarding the Modbus RTU fieldbus system should be addressed to the Modbus IDA organization.
Online: modbus-ida.org

For maintenance and support, contact the HMS support department.
Contact information is available at the support pages at www.anybus.com.


Further information and documents about this product can be found at the product pages on www.anybus.com.

Anybus X-gateway CANopen INSTALLATION SHEET

DIN-rail Mounting



To snap the gateway on, first press it downwards (1) to compress the spring in the DIN-rail mechanism, then push it against the DIN-rail as to make it snap on (2).



To snap the gateway off, push it downwards (1) and pull it out from the DIN-rail (2), as to make it snap off from the DIN-rail.

Additional Installation and Operating Instructions

Supply voltage: The X-gateway requires a regulated 24 V (21.6 V to 26.4 V) DC power source.

Field wiring terminal markings (wire type (Cu only, 14-30AWG)
"Use 60/75 or 75°C copper (CU) wire only"
Terminal tightening torque (5-7 lb-in (0.5 - 0.8 Nm)).

Use in Overvoltage Category I Pollution Degree 2 Environment.

Operating temperature/Surrounding temperature:
-25 to +55 degrees C @ 250 mA @ 24 V DC.

Maximum surface temperature: 135 degrees C.

Pressure: 850 - 1050 millibar.


This product is designed to safely operate in class I, division 2 Hazardous location according to ANSI/ISA 12.12.01-2011.

SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.

Warnings

- **WARNING - EXPLOSION HAZARD - SUBSTITUTION OF ANY COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.**
- **WARNING - EXPLOSION HAZARD - WHEN IN HAZARDOUS LOCATIONS, TURN OFF POWER BEFORE REPLACING OR WIRING MODULES.**
- **WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.**
- **WARNING - EXPLOSION HAZARD - THE USB CONNECTOR IS NOT FOR USE IN HAZARDOUS LOCATIONS AND FOR TEMPORARY CONNECTION ONLY. DO NOT USE, CONNECT OR DISCONNECT UNLESS THE AREA IS KNOWN TO BE NONHAZARDOUS. CONNECTION OR DISCONNECTION IN AN EXPLOSIVE ATMOSPHERE COULD RESULT IN AN EXPLOSION.**

UL Certification




EMC Compliance (CE)



This product is in accordance with the EMC directive 2004/108/EC through conformance with the following standards:

- **EN 61000-6-4 (2007)**
Emission standard for industrial environment
EN 55016-2-3, Class A (2006)
- **EN 61000-6-2 (2005)**
Immunity for industrial environment
EN 61000-4-2 (2009)
EN 61000-4-3 (2006)
EN 61000-4-4 (2004)
EN 61000-4-5 (2005)
EN 61000-4-6 (2007)

Label Markings



HMS Industrial Networks AB
Stationsgatan 37
302 45 Halmstad
Sweden



Further information and documents about this product can be found at the product pages on www.anybus.com.