



# Anybus<sup>®</sup> Communicator<sup>™</sup> for INTERBUS

User Manual

Doc. Id. SCM-1200-094

Rev. 3.01

---

# Important User Information

This document contains a general introduction as well as a description of the technical features provided by the Anybus Communicator, including the PC-based configuration software.

The reader of this document is expected to be familiar with PLC and software design, as well as communication systems in general. The reader is also expected to be familiar with the Microsoft Windows operating system.

## Liability

Every care has been taken in the preparation of this manual. Please inform HMS Industrial Networks AB of any inaccuracies or omissions. The data and illustrations found in this document are not binding. We, HMS Industrial Networks AB, reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be considered as a commitment by HMS Industrial Networks AB. HMS Industrial Networks AB assumes no responsibility for any errors that may appear in this document.

There are many applications of this product. Those responsible for the use of this device must ensure that all the necessary steps have been taken to verify that the applications meet all performance and safety requirements including any applicable laws, regulations, codes, and standards.

HMS Industrial Networks AB will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features, timing, or functional side effects found outside the documented scope of this product. The effects caused by any direct or indirect use of such aspects of the product are undefined, and may include e.g. compatibility issues and stability issues.

The examples and illustrations in this document are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks AB cannot assume responsibility for actual use based on these examples and illustrations.

## Intellectual Property Rights

HMS Industrial Networks AB has intellectual property rights relating to technology embodied in the product described in this document. These intellectual property rights may include patents and pending patent applications in the US and other countries.

## Trademark Acknowledgements

Anybus ® is a registered trademark of HMS Industrial Networks AB. All other trademarks are the property of their respective holders.

|   |
|---|
| <p><b>Warning:</b> This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.</p> <p><b>ESD Note:</b> This product contains ESD (Electrostatic Discharge) sensitive parts that may be damaged if ESD control procedures are not followed. Static control precautions are required when handling the product. Failure to observe this may cause damage to the product.</p> |
|---|

# Table of Contents

|                  |   |    |
|------------------|---|----|
| <b>Preface</b>   | <b>About This Document</b>                          |    |
|                  | Related Documents.....                              | 7  |
|                  | Document History .....                              | 7  |
|                  | Conventions & Terminology.....                      | 8  |
|                  | Glossary .....                                      | 8  |
|                  | Sales and Support .....                             | 9  |
| <b>Chapter 1</b> | <b>About the Anybus Communicator for INTERBUS</b>   |    |
|                  | External View .....                                 | 11 |
|                  | Status LEDs .....                                   | 12 |
|                  | Bus Speed .....                                     | 12 |
|                  | Hardware Installation .....                         | 13 |
|                  | Software Installation .....                         | 14 |
|                  | <i>Anybus Configuration Manager</i> .....           | 14 |
| <b>Chapter 2</b> | <b>Basic Operation</b>                              |    |
|                  | General.....  | 15 |
|                  | Data Exchange Model.....                            | 16 |
|                  | <i>Memory Map</i> .....                             | 16 |
|                  | <i>Data Exchange Example</i> .....                  | 17 |
|                  | Subnetwork Protocol.....                            | 18 |
|                  | <i>Protocol Modes</i> .....                         | 18 |
|                  | <i>Protocol Building Blocks</i> .....               | 18 |
|                  | <i>Master Mode</i> .....                            | 19 |
|                  | <i>Generic Data Mode</i> .....                      | 20 |
|                  | <i>DF1 Master Mode</i> .....                        | 20 |
|                  | INTERBUS-S Implementation.....                      | 21 |
|                  | <i>General</i> .....                                | 21 |
|                  | <i>Data Representation</i> .....                    | 21 |
|                  | <i>Memory Layout (Internal Memory Buffer)</i> ..... | 22 |
| <b>Chapter 3</b> | <b>Navigating the Anybus Configuration Manager</b>  |    |
|                  | Main Window .....                                   | 23 |
|                  | <i>Pull-down Menu</i> .....                         | 24 |
|                  | <i>Toolbar Icons</i> .....                          | 27 |

|                  |  |    |
|------------------|--|----|
| <b>Chapter 4</b> | <b>Basic Settings</b>  |    |
|                  | Fieldbus Settings.....   | 28 |
|                  | ABC Parameters .....   | 29 |
|                  | Subnetwork Parameters.....   | 31 |
| <b>Chapter 5</b> | <b>Nodes</b>   |    |
|                  | General.....   | 32 |
|                  | Adding & Managing Nodes.....   | 32 |
|                  | Node Parameters .....  | 32 |
|                  | <i>Master Mode and Generic Data Mode</i> .....                       | 32 |
| <b>Chapter 6</b> | <b>Transactions</b>  |    |
|                  | General.....   | 33 |
|                  | Adding & Managing Transactions.....                                  | 34 |
|                  | Transaction Parameters (Master Mode).....                            | 35 |
|                  | <i>Parameters (Query &amp; Broadcast)</i> .....                      | 35 |
|                  | <i>Parameters (Response)</i> .....                                   | 37 |
|                  | Transaction Parameters (Generic Data Mode).....                      | 37 |
|                  | <i>Produce-Transactions</i> .....                                    | 37 |
|                  | <i>Consume-Transactions</i> .....                                    | 38 |
|                  | Transaction Editor .....   | 39 |
| <b>Chapter 7</b> | <b>Frame Objects</b>   |    |
|                  | General.....   | 40 |
|                  | Adding and Editing Frame Objects .....                               | 40 |
|                  | Constant Objects (Byte, Word, Dword).....                            | 41 |
|                  | Limit Objects (Byte, Word, Dword) .....                              | 42 |
|                  | Data Object.....   | 43 |
|                  | Variable Data Object.....  | 43 |
|                  | Checksum Object.....   | 45 |
| <b>Chapter 8</b> | <b>Commands</b>  |    |
|                  | General.....   | 46 |
|                  | Adding & Managing Commands .....                                     | 46 |
|                  | <i>Pull-Down Menu</i> .....  | 47 |
|                  | <i>Toolbar Icons</i> .....   | 47 |
|                  | The Command Editor .....   | 48 |
|                  | <i>General</i> .....   | 48 |
|                  | <i>Basic Navigation</i> .....  | 48 |
|                  | <i>Pull-down Menu</i> .....  | 49 |
|                  | <i>Editing a Command</i> .....                                       | 50 |
|                  | <i>Example: Specifying a Modbus-RTU Command in Master Mode</i> ..... | 51 |

|                   |   |    |
|-------------------|---|----|
| <b>Chapter 9</b>  | <b>DF1 Protocol Mode</b>                                      |    |
|                   | General.....  | 52 |
|                   | ABC Parameters .....  | 53 |
|                   | Subnetwork Parameters.....                                    | 54 |
|                   | Node Parameters .....   | 55 |
|                   | Services .....  | 55 |
|                   | <i>Available Services</i> .....                               | 56 |
|                   | Integrity Check .....   | 57 |
|                   | Read Diagnostics .....  | 57 |
|                   | Read Data .....   | 58 |
|                   | Write Data .....  | 58 |
| <br>              |   |    |
| <b>Chapter 10</b> | <b>Subnetwork Monitor</b>                                     |    |
| <br>              |   |    |
| <b>Chapter 11</b> | <b>Node Monitor</b>   |    |
|                   | General.....  | 60 |
|                   | Navigating the Node Monitor.....                              | 61 |
|                   | <i>Pull-Down Menu</i> .....                                   | 62 |
|                   | <i>Toolbar Icons</i> .....                                    | 63 |
| <br>              |   |    |
| <b>Chapter 12</b> | <b>Data Logger</b>  |    |
|                   | General.....  | 64 |
|                   | Operation.....  | 64 |
|                   | Configuration.....  | 65 |
| <br>              |   |    |
| <b>Chapter 13</b> | <b>Configuration Wizards</b>                                  |    |
|                   | General.....  | 66 |
|                   | Selecting a Wizard Profile .....                              | 66 |
|                   | Wizard - Modbus RTU Master .....                              | 67 |
| <br>              |   |    |
| <b>Chapter 14</b> | <b>Control and Status Registers</b>                           |    |
|                   | General.....  | 68 |
|                   | <i>Handsbaking Procedure</i> .....                            | 68 |
|                   | <i>Data Consistency</i> .....                                 | 69 |
|                   | Status Register Contents (Gateway to Control System).....     | 70 |
|                   | <i>General Information</i> .....                              | 70 |
|                   | <i>Status Codes in Master Mode and DF1 Master Mode</i> .....  | 70 |
|                   | <i>Status Code in Generic Data Mode</i> .....                 | 71 |
|                   | Control Register Contents (Control System to Gateway).....    | 72 |
|                   | <i>General Information</i> .....                              | 72 |
|                   | <i>Control Codes in Master Mode and DF1 Master Mode</i> ..... | 72 |
|                   | <i>Control Codes in Generic Data Mode</i> .....               | 72 |

|                   |  |    |
|-------------------|--|----|
| <b>Chapter 15</b> | <b>Advanced Fieldbus Configuration</b>                     |    |
|                   | General.....   | 73 |
|                   | Mailbox Editor.....  | 73 |
| <b>Appendix A</b> | <b>PCP Bandwidth Configuration</b>                         |    |
|                   | General.....   | 74 |
|                   | Add a Mailbox Message .....                                | 74 |
|                   | Specifying the PCP Bandwidth .....                         | 75 |
| <b>Appendix B</b> | <b>Connector Pin Assignments</b>                           |    |
|                   | Bus-in Connector (INTERBUS) .....                          | 76 |
|                   | Bus-out Connector (INTERBUS).....                          | 76 |
|                   | Power Connector .....                                      | 76 |
|                   | PC Connector .....   | 77 |
|                   | Subnetwork Interface .....                                 | 78 |
|                   | <i>General Information</i> .....                           | 78 |
|                   | <i>Bias Resistors (RS485 Only)</i> .....                   | 78 |
|                   | <i>Termination (RS485 &amp; RS422 Only)</i> .....          | 78 |
|                   | <i>Connector Pinout (DB9F)</i> .....                       | 78 |
|                   | <i>Typical Connection (RS485)</i> .....                    | 79 |
|                   | <i>Typical Connection (RS422 &amp; 4-Wire RS485)</i> ..... | 79 |
|                   | <i>Typical Connection (RS232)</i> .....                    | 79 |
| <b>Appendix C</b> | <b>Technical Specification</b>                             |    |
|                   | Mechanical Properties.....                                 | 80 |
|                   | Electrical Characteristics .....                           | 80 |
|                   | Environmental Characteristics .....                        | 80 |
|                   | Regulatory Compliance .....                                | 81 |
| <b>Appendix D</b> | <b>Troubleshooting</b>                                     |    |
| <b>Appendix E</b> | <b>ASCII Table</b>   |    |

## About This Document

For more information, documentation etc., please visit the HMS website, [www.anybus.com](http://www.anybus.com).

## Related Documents

| Document name  | Author        |
|--|---------------|
| ABC-IBS Installation Leaflet   | HMS           |
| DF1 Protocol and Command Set - Reference Manual, 1770-6.5.16, October 1996 | Allen-Bradley |
|  |               |
|  |               |
|  |               |
|  |               |
|  |               |
|  |               |

## Document History

### Summary of Recent Changes (3.00... 3.01)

| Change   | Page(s) |
|--|---------|
| Updated software name "Anybus Config Tool" to "Anybus Configuration Manager" | -       |
| Changed the number of possible transactions                                  | 33      |
| Updated information about the trigger byte                                   | 38      |
| Updated information about the CRC-algorithm                                  | 45      |
| Updated frontpage information  | -       |
| Updated sales and support page   | -       |
| Updated System Requirements for Anybus Configuration Manager                 | 14      |
|  |         |

### Revision List

| Revision | Date       | Author | Chapter | Description   |
|----------|------------|--------|---------|---|
| 2.00     | 2006-04-11 | PeP    | All     | 1st release   |
| 2.01     | 2006-12-22 | PeP    | -       | Misc. minor corrections & updates                                   |
| 2.02     | 2008-06-03 | PeP    | 4, A    | Minor update  |
| 2.03     | 2009-04-23 | KeL    | All     | Misc. minor corrections and updates                                 |
| 3.00     | 2011-02-08 | KaD    | All     | Misc minor corrections, new template and DF1 functionality          |
| 3.01     | 2011-09-30 | KaD    | All     | Misc corrections and updates, new Anybus Configuration Manager name |
|          |            |        |         |   |
|          |            |        |         |   |
|          |            |        |         |   |
|          |            |        |         |   |
|          |            |        |         |   |
|          |            |        |         |   |

## Conventions & Terminology

The following conventions are used throughout this document:

- Numbered lists provide sequential steps
- Bulleted lists provide information, not procedural steps
- The term ‘user’ refers to the person or persons responsible for installing the Anybus Communicator in a network.
- The term ‘ABC’ refers to the Anybus Communicator.
- Hexadecimal values are written in the format 0xNNNN, where NNNN is the hexadecimal value.
- Decimal values are represented as NNNN where NNNN is the decimal value
- As in all communication systems, the terms “input” and “output” can be ambiguous, because their meaning depend on which end of the link is being referenced. The convention in this document is that “input” and “output” are always being referenced to the master/scanner end of the link.

## Glossary

| Term                    | Meaning   |
|-------------------------|---|
| ABC                     | Anybus <sup>®</sup> Communicator <sup>™</sup>   |
| Broadcaster             | A protocol-specific node in the configuration that handles transactions destined to all nodes.  |
| IBS                     | INTERBUS-S  |
| Command                 | A predefined transaction.   |
| Configuration           | List of configured nodes with transactions on the subnetwork.   |
| Fieldbus                | The higher level network to which the communicator is connected.  |
| Fieldbus Control System | Fieldbus master   |
| Frame Object            | Low level entities which are used to describe the different parts of a transaction.   |
| Monitor                 | A tool for debugging the Anybus Communicator and the network connections.   |
| Node                    | A device in the configuration which defines the communication with a node on the subnetwork   |
| Subnetwork              | The network that is logically located on a subsidiary level with respect to the fieldbus, and to which the Anybus Communicator acts as a gateway. |
| Transaction             | A generic building block that is used in the subnetwork configuration and defines the data that is sent and received on the subnetwork.           |
| User                    | Person or persons responsible for installing the Anybus Communicator  |
| Higher Level Network    | In this case, INTERBUS  |
| Network                 |   |
| Fieldbus                |   |




# Sales and Support

| Sales                           |                           | Support    |                             |
|---------------------------------|---------------------------|------------|-----------------------------|
| <b>HMS Sweden (Head Office)</b> |                           |            |                             |
| E-mail:                         | sales@hms.se              | E-mail:    | support@hms-networks.com    |
| Phone:                          | +46 (0) 35 - 17 29 56     | Phone:     | +46 (0) 35 - 17 29 20       |
| Fax:                            | +46 (0) 35 - 17 29 09     | Fax:       | +46 (0) 35 - 17 29 09       |
| Online:                         | www.anybus.com            | Online:    | www.anybus.com              |
| <b>HMS North America</b>        |                           |            |                             |
| E-mail:                         | us-sales@hms-networks.com | E-mail:    | us-support@hms-networks.com |
| Phone:                          | +1-312 - 829 - 0601       | Phone:     | +1-312-829-0601             |
| Toll Free:                      | +1-888-8-Anybus           | Toll Free: | +1-888-8-Anybus             |
| Fax:                            | +1-312-629-2869           | Fax:       | +1-312-629-2869             |
| Online:                         | www.anybus.com            | Online:    | www.anybus.com              |
| <b>HMS Germany</b>              |                           |            |                             |
| E-mail:                         | ge-sales@hms-networks.com | E-mail:    | ge-support@hms-networks.com |
| Phone:                          | +49 (0) 721-989777-000    | Phone:     | +49 (0) 721-989777-000      |
| Fax:                            | +49 (0) 721-989777-010    | Fax:       | +49 (0) 721-989777-010      |
| Online:                         | www.anybus.de             | Online:    | www.anybus.de               |
| <b>HMS Japan</b>                |                           |            |                             |
| E-mail:                         | jp-sales@hms-networks.com | E-mail:    | jp-support@hms-networks.com |
| Phone:                          | +81 (0) 45-478-5340       | Phone:     | +81 (0) 45-478-5340         |
| Fax:                            | +81 (0) 45-476-0315       | Fax:       | +81 (0) 45-476-0315         |
| Online:                         | www.anybus.jp             | Online:    | www.anybus.jp               |
| <b>HMS China</b>                |                           |            |                             |
| E-mail:                         | cn-sales@hms-networks.com | E-mail:    | cn-support@hms-networks.com |
| Phone:                          | +86 (0) 10-8532-3183      | Phone:     | +86 (0) 10-8532-3023        |
| Fax:                            | +86 (0) 10-8532-3209      | Fax:       | +86 (0) 10-8532-3209        |
| Online:                         | www.anybus.cn             | Online:    | www.anybus.cn               |
| <b>HMS Italy</b>                |                           |            |                             |
| E-mail:                         | it-sales@hms-networks.com | E-mail:    | it-support@hms-networks.com |
| Phone:                          | +39 039 59662 27          | Phone:     | +39 039 59662 27            |
| Fax:                            | +39 039 59662 31          | Fax:       | +39 039 59662 31            |
| Online:                         | www.anybus.it             | Online:    | www.anybus.it               |
| <b>HMS France</b>               |                           |            |                             |
| E-mail:                         | fr-sales@hms-networks.com | E-mail:    | fr-support@hms-networks.com |
| Phone:                          | +33 (0) 3 68 368 034      | Phone:     | +33 (0) 3 68 368 033        |
| Fax:                            | +33 (0) 3 68 368 031      | Fax:       | +33 (0) 3 68 368 031        |
| Online:                         | www.anybus.fr             | Online:    | www.anybus.fr               |
| <b>HMS UK &amp; Eire</b>        |                           |            |                             |
| E-mail:                         | uk-sales@anybus.co.uk     | E-mail:    | support@hms-networks.com    |
| Phone:                          | +44 (0) 1926 405599       | Phone:     | +46 (0) 35 - 17 29 20       |
| Fax:                            | +44 (0) 1926 405522       | Fax:       | +46 (0) 35 - 17 29 09       |
| Online:                         | www.anybus.co.uk          | Online:    | www.anybus.com              |
| <b>HMS Denmark</b>              |                           |            |                             |
| E-mail:                         | info@anybus.dk            | E-mail:    | support@hms-networks.com    |
| Phone:                          | +45 (0) 22 30 08 01       | Phone:     | +46 (0) 35 - 17 29 20       |
| Fax:                            | +46 (0) 35 17 29 09       | Fax:       | +46 (0) 35 - 17 29 09       |
| Online:                         | www.anybus.com            | Online:    | www.anybus.com              |
| <b>HMS India</b>                |                           |            |                             |
| E-mail:                         | in-sales@anybus.com       | E-mail:    | in-support@hms-networks.com |
| Phone:                          | +91 (0) 20 40111201       | Phone:     | +46 (0) 35 - 17 29 20       |
| Fax:                            | +91 (0) 20 40111105       | Fax:       | +46 (0) 35 - 17 29 09       |
| Online:                         | www.anybus.com            | Online:    | www.anybus.com              |

# 1. About the Anybus Communicator for INTERBUS

The Anybus Communicator for INTERBUS acts as a gateway between virtually any serial application protocol and a INTERBUS-S-based network. Integration of industrial devices is enabled without loss of functionality, control and reliability, both when retro-fitting to existing equipment as well as when setting up new installations.



## Subnetwork

The Anybus Communicator can address up to 31 nodes, and supports the following physical standards:

- RS-232
- RS-422
- RS-485

## INTERBUS Interface

INTERBUS connectivity is provided through patented Anybus technology; a proven industrial communication solution used all over the world by leading manufacturers of industrial automation products.

- 500kbit or 2Mbit operation
- Up to 20 bytes of process data in each direction
- PCP V.2.0. (0, 1, 2, or 4 words)
- Galvanically isolated bus electronics

## 1.1 External View

For wiring and pin assignments, see “Connector Pin Assignments” on page 76.

### A: Bus-In Connector

See also...

- “Bus-in Connector (INTERBUS)” on page 76

### B: Bus-Out Connector

See also...

- “Bus-out Connector (INTERBUS)” on page 76

### C: Baudrate Jumper

See also...

- “Bus Speed” on page 12

### D: Status LEDs

See also...

- “Status LEDs” on page 12

### E: PC connector

This connector is used to connect the Anybus Communicator to a PC for configuration and monitoring purposes.

See also...

- “Hardware Installation” on page 13
- “PC Connector” on page 77

### F: Subnetwork Connector

This connector is used to connect the gateway to the serial subnetwork.

See also...

- “Hardware Installation” on page 13
- “Subnetwork Interface” on page 78

### G: Power Connector

This connector is used to apply power to the gateway.

See also...


- “Hardware Installation” on page 13
- “Power Connector” on page 76
- “Technical Specification” on page 80

### H: DIN-rail Connector

The DIN-rail mechanism connects the gateway to PE (Protective Earth).


See also...

- “Hardware Installation” on page 13



## 1.2 Status LEDs


| #                              | State                 | Status  |
|--------------------------------|-----------------------|---|
| 1 - BA                         | Off                   | -   |
|                                | Green                 | Bus active  |
| 2 - TR                         | Off                   | -   |
|                                | Green                 | PCP-communication active  |
| 3 - CC/RC                      | Off                   | -   |
|                                | Green                 | Connection ok, INTERBUS master not in reset   |
| 4 - RD                         | Off                   | -   |
|                                | Yellow                | Remote bus disabled   |
| 5 - Subnet Status <sup>a</sup> | Off                   | Power off   |
|                                | Green, flashing       | Running correctly, but one or more transaction error(s) have occurred   |
|                                | Green                 | Running   |
|                                | Red                   | Transaction error/timeout or subnet stopped   |
| 6 - Device Status              | Off                   | Power off   |
|                                | Alternating Red/Green | Invalid or missing configuration  |
|                                | Green                 | Initializing  |
|                                | Green, flashing       | Running   |
|                                | Red                   | Bootloader mode <sup>b</sup>  |
|                                | Red, flashing         | If the Device Status LED is flashing in a sequence starting with one or more red flashes, please note the sequence pattern and contact the HMS support department |



- a. This led turns green when all transactions have been active at least once. This includes any transactions using “change of state” or “change of state on trigger”. If a timeout occurs on a transaction, this led will turn red.
- b. The gateway is in bootloader mode, and firmware must be restored in order for it to work properly. Start up the Anybus Configuration Manager and connect to the Anybus Communicator. Choose Tools/Options/ABC. Click “Factory Restore” to restore firmware. See “Tools” on page 25.

## 1.3 Bus Speed

The Anybus Communicator supports both 500kbit and 2Mbit operation. The bus speed is selected using the on-board jumper as follows:




## 1.4 Hardware Installation


Perform the following steps when physically installing the Anybus Communicator:

1. Snap the gateway on to the DIN-rail (See “DIN-rail Connector” on page 11)

The DIN-rail mechanism works as follows:



To snap the gateway *on*, first press it downwards (1) to compress the spring in the DIN-rail mechanism, then push it against the DIN-rail as to make it snap on (2)



To snap the gateway *off*, push it downwards (1) and pull it out from the DIN-rail (2), as to make it snap off from the DIN-rail

2. Connect the gateway to the INTERBUS network
3. Connect the gateway to the serial subnetwork
4. Connect the gateway to the PC via the Configuration Cable
5. Connect the power cable and apply power
6. Start the Anybus Configuration Manager program on the PC  
(The Anybus Configuration Manager software attempts to detect the serial port automatically. If not successful, select the correct port manually in the “Port”-menu)
7. Configure the gateway using the Anybus Configuration Manager and download the configuration

## 1.5 Software Installation

### 1.5.1 Anybus Configuration Manager

#### System requirements

- Pentium 133 MHz or higher
- 650 MB of free space on the hard drive
- 32 MB RAM
- Screen resolution of 800x600 (16 bit color) or higher
- Microsoft Windows™ 2000 / XP / Vista / 7 (32 bit)
- Internet Explorer 4.01 SP1 or newer

#### Installation

- **Anybus Communicator resource CD**

Insert the CD and follow the on-screen instructions. If the installation does not start automatically, right-click on the CD-drive icon and select Explore. Execute 'setup.exe' and follow the on-screen instructions.

- **From website**

Download and execute the self-extracting .exe-file from the HMS website ([www.anybus.com](http://www.anybus.com)).


## 2. Basic Operation

### 2.1 General

The Anybus Communicator is designed to exchange data between a serial subnetwork and a higher level network. Unlike most other gateway devices of similar kind, it does not have a fixed protocol for the subnetwork, and can be configured to handle almost any form of serial communication.

The gateway can issue serial telegrams cyclically, on change of state, or based on trigger events issued by the control system of the higher level network (i.e. the fieldbus master or PLC). It can also monitor certain aspects of the subnetwork communication and notify the higher level network when data has changed.

An essential part of the Anybus Communicator package is the Anybus Configuration Manager, a Windows™ application which is used to supply the gateway with a description of the subnetwork protocol. No programming skills are required; instead, a visual protocol description-system is used to specify the different parts of the serial communication.



## 2.2 Data Exchange Model

Internally, the data exchanged on the subnetwork, and the data exchanged on the higher level network, resides in the same memory.

This means that in order to exchange data with the subnetwork, the higher level network simply reads and writes data to memory locations specified using the Anybus Configuration Manager. The very same memory locations can then be exchanged on the subnetwork.

The internal memory buffer is divided into three areas based on their function:

- **Input Data (Up to 512 bytes)**

This area can be read by the higher level network.

(how this data is represented on the higher level network will be described later in this chapter).


- **Output Data (Up to 512 bytes)**

This area can be written to by the higher level network.

(how this data is represented on the higher level network will be described later in this chapter).


- **General Data**

This area cannot be accessed from the higher level network, but can be used for transfers between individual nodes on the subnetwork, or as a general “scratch pad” for data. The actual size of this area depends on the amount of data that is exchanged on the subnetwork. The gateway can handle up to 1024 bytes of general data.



### 2.2.1 Memory Map


When building the subnetwork configuration using the Anybus Configuration Manager, the different areas described above are mapped to the memory locations (addresses) specified below.





## 2.2.2 Data Exchange Example

In the following example, a temperature regulator on the subnetwork exchanges information with a PLC on the higher level network, via the internal memory buffers in the Anybus Communicator.



## 2.3 Subnetwork Protocol

### 2.3.1 Protocol Modes

The Anybus Communicator features three distinct modes of operation regarding the subnetwork communication, called ‘Master Mode’, ‘DF1 Master Mode’ and ‘Generic Data Mode’. Note that the protocol mode only specifies the basic communication model, not the actual subnetwork protocol.

- **Master Mode**

In this mode, the gateway acts as a master on the subnetwork, and the serial communication takes place in a query-response fashion. The nodes on the network are not permitted to issue messages unless they have been addressed by the gateway first.

For more information about this mode, see “Master Mode” on page 19.

- **DF1 Master Mode**

In this mode, the gateway acts as a master on the subnetwork, using the DF1 protocol. The serial communication takes place in a query-response fashion. For more information about this mode, see “DF1 Protocol Mode” on page 52.

- **Generic Data Mode**

In this mode, there is no master-slave relationship between the subnetwork nodes and the gateway; any node on the subnetwork, including the gateway, may spontaneously produce or consume messages.

For more information about this mode, see “Generic Data Mode” on page 20.

### 2.3.2 Protocol Building Blocks

The following building blocks are used in Anybus Configuration Manager to describe the subnetwork communication. How these blocks apply to the three protocol modes will be described later in this document.

- **Node**

A node represents a single device on the subnetwork. Each node can be associated with a number of transactions, see below.

- **Transaction**

A ‘transaction’ represents a complete serial telegram, and consists of a number of frame objects (see below). Each transaction is associated with a set of parameters controlling how and when to use it on the subnetwork.

- **Commands**

A ‘command’ is simply a predefined transaction stored in a list in the Anybus Configuration Manager. This simplifies common operations by allowing transactions to be stored and reused.


- **Frame Object**

‘Frame objects’ are low level entities used to compose a transaction (see above). A Frame object can represent a fixed value (a constant), a range of values (limit objects), a block of data or a calculated checksum.

### 2.3.3 Master Mode

In this mode, the communication is based on a query-response scheme; when the Anybus Communicator issues a query on the subnetwork, the addressed node is expected to issue a response to that query. Nodes are not permitted issue responses spontaneously, i.e. without first receiving a query.


There is one exception to this rule; the broadcaster. Most protocols offer some way of broadcasting messages to all nodes on the network, without expecting them to respond to the broadcasted message. This is also reflected in the gateway, which features a dedicated broadcaster node.



In master mode, Anybus Configuration Manager comes preloaded with most commonly used Modbus RTU commands, which can conveniently be reached by right-clicking on a node in the Anybus Configuration Manager and selecting 'Insert New Command'. Note however that this does not in any way prevent other protocols based on the same query-response message-scheme to be implemented.

### 2.3.4 Generic Data Mode

In this mode, there is no master-slave relationship between the nodes on the subnetwork and the Anybus Communicator. Any node, including the gateway, may spontaneously produce or consume a message. Nodes do not have to respond to messages, nor do they have to wait for a query in order to send one.



In the figure above, the gateway ‘consumes’ data that is ‘produced’ by a node on the subnetwork. This ‘consumed’ data can then be accessed from the higher level network. This also works the other way around; the data received from the higher level network is used to ‘produce’ a message on the subnetwork to be ‘consumed’ by a node.

### 2.3.5 DF1 Master Mode

Please refer to “DF1 Protocol Mode” on page 52.

## 2.4 INTERBUS-S Implementation

### 2.4.1 General

The Anybus Communicator acts as a slave on the INTERBUS network. As such, it does not initiate communication towards other nodes by itself, but can be read from/written to by an INTERBUS master.

The input and output data areas in the internal memory buffer are represented as process data (cyclical data), and optionally through PCP (acyclical data).

### 2.4.2 Data Representation

#### Process Data (IO Data)

The Anybus Communicator supports up to 20 bytes of process data in each direction. Note however that when using PCP-communication (see below), the data size must not exceed 18 bytes, since one word is needed to manage the PCP-communication. The process data sizes are set using the Anybus Configuration Manager (IO Sizes).

See also...

- “Memory Layout (Internal Memory Buffer)” on page 22
- “IO Sizes” on page 28

#### PCP Objects

The PCP data is grouped into objects, each holding up to 32 bytes of data.

In the gateway, the objects are numbered as follows:

| PCP Object | Area             | Memory Location in ABC                                   |
|------------|------------------|--|
| 0x6000     | Output Data area | (IO Data OUT Size + 0x200)... (IO Data OUT Size + 0x21F) |
| 0x6001     | Output Data area | (IO Data OUT Size + 0x220)... (IO Data OUT Size + 0x23F) |
| ...        | ...              | ...  |
| 0x600F     | Output Data area | (IO Data OUT Size + 0x3E0)... (IO Data OUT Size + 0x3FF) |
| 0x6040     | Input Data area  | (IO Data IN Size + 0x000)... (IO Data IN Size + 0x01F)   |
| 0x6041     | Input Data area  | (IO Data IN Size + 0x020)... (IO Data IN Size + 0x03F)   |
| ...        | ...              | ...  |
| 0x604F     | Input Data area  | (IO Data IN Size + 0x1E0)... (IO Data IN Size + 0x1FF)   |

See also...

- “Memory Layout (Internal Memory Buffer)” on page 22
- “IO Sizes” on page 28

## 2.4.3 Memory Layout (Internal Memory Buffer)

The process data and the PCP objects correlate to gateway memory as follows:

- **Process Data (IO Data)**

The process data occupies the very beginning of the input and output data areas. As mentioned previously, the number of bytes occupied by process data is specified in the Anybus Configuration Manager.

See also...

- “IO Sizes” on page 28

- **PCP Data**

The PCP objects are located directly following the process data. The starting offset in gateway memory depends on the IO sizes specified in the Anybus Configuration Manager.

See also...

- “IO Sizes” on page 28


*Example:*

In this example, the IO sizes in Anybus Configuration Manager is set as follows:

IO Size In= 16 bytes(0x0010)

IO Size Out= 16 bytes(0x0010)

Resulting memory layout:




See also...

- “General” on page 21
- “Data Representation” on page 21

## 3. Navigating the Anybus Configuration Manager

### 3.1 Main Window

The main window in the Anybus Configuration Manager can be divided into 4 sections as follows:



- **A: Pull-down Menus & Tool Bar**

The second drop-down menu from the left will change depending on the current context. The Tool Bar provides quick access to the most frequently used functions.

- **B: Navigation Section**

This section is the main tool for selecting and altering different levels of the subnetwork configuration.

Entries preceded by a '+' holds further configuration parameters or 'sub menus'. To gain access to these parameters, the entry must be expanded by clicking '+'. There are three main levels in the navigation window, namely Fieldbus, ABC and subnetwork.

Right-clicking on entries in this section brings out additional selections related to that particular entry.


- **C: Parameter Section**

This section holds a list of parameters or options related to the currently selected entry in the Navigation Section.

The parameter value may be specified either using a selection box or manually, depending on the parameter itself. Values can be specified in decimal form (e.g. '42'), or in hexadecimal format (e.g. '0x2A').

- **D: Information Section**

This section holds information related to the currently selected parameter.



| Configuration:           |       |
|--------------------------|-------|
| Alphabetic Categorized   |       |
| Communication            |       |
| Bitrate (bits/s)         | 9600  |
| Data bits                | 8     |
| Parity                   | None  |
| Physical standard        | RS232 |
| Start bits               | 1     |
| Stop bits                | 1     |
| Timing                   |       |
| Message delimiter (10ms) | 0     |

**Parameter Section**

|                                 |
|---------------------------------|
| <b>Message delimiter (10ms)</b> |
| The time between transaction    |


**Information Section**

### 3.1.1 Pull-down Menu

#### File


This menu features the following entries:

- **New**  
Create a new configuration.  
See also “Configuration Wizards” on page 67.
- **Open...**  
Open a previously created configuration.
- **Save**  
Save the current configuration.
- **Save As...**  
Save the current configuration under a new name.
- **Print...**  
Send details about the current configuration to a printer.
- **Properties...**



This brings out the following window:

| Item                                | Description  |
|-------------------------------------|--|
| Select a Name for the Configuration | A name for the configuration may be entered here                               |
| Download Password(6)                | These fields can be used to password-protect the configuration in the gateway. |
| Upload Password(6)                  |  |



**CAUTION:** Always keep a copy of the password in a safe place. A lost password cannot be retrieved!


- **Exit**  
Close the Anybus Configuration Manager.



## Tools


This menu features the following entries:

- **Port**  
This entry selects the COM-port used for the configuration of the gateway.
- **Upload configuration from ABC**  
Upload the configuration from the gateway to the Anybus Configuration Manager.
- **Download configuration to ABC**  
Download the current configuration into the gateway.
- **Start Logging**  
Start the Data Logger (see “Data Logger” on page 64).  
Note that when the Data Logger is active, this menu entry is changed to ‘Stop Logging’.




- **Options**  
This will bring out the following window:

| Item                                       | Description  |
|--|--|
| Warning on Delete                          | A confirmation dialog is displayed each time something is deleted.                                   |
| Warning on unsaved data                    | A confirmation dialog is displayed when closing the Anybus Configuration Manager with unsaved data.  |
| Show Wizard when “New” menu is selected    | The Wizard is displayed each time a new configuration is created.                                    |
| Language next time the program is launched | Selects which language to use. The new setting will be active the next time the program is launched. |



Selecting the ‘ABC’-tab will reveal additional properties:


| Item                | Description  |
|---------------------|--|
| Size of logbuffer   | By default, the Data Logger can log up to 512 entries in each direction. If necessary, it is possible to specify a different number of entries (valid settings range from 1...512). Click ‘Apply’ to validate the new settings. See also “Data Logger” on page 64. |
| Firmware Download   | Download firmware to the embedded fieldbus interface.<br><b>Warning: Use with caution.</b>   |
| Factory Restore     | Restores the gateway firmware to it’s original state (does not affect the embedded fieldbus interface).  |
| Block Configuration | When selected, the downloaded configuration will not be executed by the gateway.<br><b>Warning: Use with caution.</b>  |
| Create Error log    | Creates an error log file  |



## View

This menu features the following entries:


- **Toolbar**  
This entry enables/disables the toolbar icons at the top of the main window.
- **Status Bar**  
This entry enables/disables the status bar at the bottom of the main window.



## Help

This menu features the following entries:




- **Contents**  
Display the table of contents of the online help system.  
**Note:** At the time of writing, no online help system exists.
- **Search For Help On...**  
Search for a particular topic in the online help system.  
**Note:** At the time of writing, no online help system exists.
- **About...**  
Display general information about the gateway and the current build of Anybus Configuration Manager.





### 3.1.2 Toolbar Icons

The toolbar features icons for the most commonly used functions.


- **New, Open & Save**  
See “File” on page 24.






New
Open
Save
  
- **Upload from ABC & Download to ABC**  
See “Tools” on page 25.


Upload
Download
  
- **Up one Level**  
Clicking on this icon will move the selection in the navigation section.




Up one Level
  
- **Cut, Copy, Paste, Delete, Insert**  
These icons are used for common editing functions in the navigation section.



Cut
Copy
Paste
Delete
Insert
  
- **Connect**  
Clicking on this icon will cause the Anybus Configuration Manager to attempt to connect to the gateway.




Connect
  
- **Disconnect**  
Clicking on this icon will cause the Anybus Configuration Manager to disconnect from the gateway.




Disconnect
  
- **Start Logging & Stop Logging**  
See “Tools” on page 25 & “Data Logger” on page 64.


Start Log.
Stop Log.
  
- **Subnetwork Monitor**  
Clicking on this icon will launch the subnetwork Monitor (see “Subnetwork Monitor” on page 59).





Sub-Network Monitor
  
- **Add Command**  
This icon is used to add commands to the currently selected node.




Add Command
  
- **Add Mailbox**  
(Advanced functionality, see “Mailbox Editor” on page 73)





Add Mailbox
  
- **Add Node & Add Broadcaster**  
These icons are used to add nodes to the configuration.

Node
Broadcaster
  
- **Node Monitor**  
Clicking on this icon will launch the Node Monitor (see “Node Monitor” on page 60)



Node Monitor
  
- **Add Transaction(s)**  
These icons are used to add transactions to the currently selected node.

Add Transactions
Add Transaction

## 4. Basic Settings

### 4.1 Fieldbus Settings

(Select 'Fieldbus' in the Navigation Section to gain access to the parameters described in this section).



#### General

During start-up the fieldbus interface of the Anybus Communicator is initialized to fit the configuration created in the Anybus Configuration Manager. Optionally, some initialization parameters can be set manually to provide better control over how the data shall be treated by the gateway.

#### Fieldbus Type

The Anybus Configuration Manager supports a wide range of networking systems. Make sure that this parameter is set to 'INTERBUS-S'.

#### IO Sizes

These parameters specify how data from the internal memory buffer shall be exchanged on INTERBUS.


This can either be handled automatically based on the subnetwork configuration, or specified manually.

- **Automatic**


All data will be exchanged as process data. Note however that if the size of the configuration exceeds 20 bytes in any direction, the gateway will be unable to start up the INTERBUS communication.

- **User Defined (Recommended)**

Additional parameter properties appear; 'IO Size In' and 'IO Size Out'. The specified amount, starting at address 0x0000 of the respective memory buffers, will be exchanged as process data. The remainder will be exchanged through PCP, provided that the specified parameter value is less than or equal to 18.



Fieldbus Type



IO Sizes

**Note 1:** It is generally recommended to enter user defined IO sizes, since the 'Automatic'-option doesn't work for configurations where the data size exceeds 20 bytes in any direction.

**Note 2:** By default, the gateway uses 1 word for PCP transmission. Other PCP transmission sizes can be specified using the Mailbox Editor (see "PCP Bandwidth Configuration" on page 74)

See also...

- "INTERBUS-S Implementation" on page 21
- "Data Representation" on page 21
- "Memory Layout (Internal Memory Buffer)" on page 22
- "PCP Bandwidth Configuration" on page 74

## 4.2 ABC Parameters

(Select 'ABC' in the Navigation Section to gain access to the parameters described in this section).



### Interface

Currently, only serial communication is supported.

### Status / Control Word

(See “Control and Status Registers” on page 68).

| Value                       | Description   |
|-----------------------------|---|
| Enabled                     | Enable the Control and Status Registers. The 'Data Valid'-bit in the Control Register must be set to start the subnetwork communication.                |
| Enabled but no startup lock | This setting is similar to 'Enabled', except that the control system is not required to set the 'Data Valid'-bit to start the subnetwork communication. |
| Disabled                    | This setting completely disables the Control and Status Registers.  |

### Module Reset

This parameter specifies how the gateway will behave in the event of a fatal error.

| Value    | Description  |
|----------|--|
| Enabled  | The gateway will be restarted, and no error will be indicated to the user. |
| Disabled | The gateway will halt and indicate an error.                               |

### Protocol Mode

This parameter specifies which protocol mode to use for the subnetwork.

| Value             | Description  |
|-------------------|--|
| Generic Data Mode | This mode is primarily intended for Produce & Consume-based protocols, where there are no Master-Slave relationship between the gateway and the nodes on the subnetwork.   |
| Master Mode       | This mode is intended for 'Query & Response'-based protocols, where a single Master exchanges data with a number of Slaves.  |
| DF1               | This mode is intended for the DF1 protocol. The Anybus Communicator can only be configured as a Master with half-duplex communication.<br><b>Note:</b> This is the only mode available if you intend to configure an ABC module for DF1. |

See also “Protocol Modes” on page 19.

## Statistics

The Transmit- and Receive Counters indicate how many transactions that have successfully been exchanged on the subnetwork. This feature is primarily intended for debugging purposes.

- **Receive Counter Location**  
Specifies the location of the Receive Counter in the internal memory buffer.
- **Transmit Counter Location**  
Specifies the location of the Transmit Counter in the internal memory buffer.

Both counters are enabled by setting 'Statistics' to 'Enabled'.

## 4.3 Subnetwork Parameters

(To gain access to the parameters described in this section, select 'Subnetwork' in the Navigation Section).



### Communication

These parameters specify the actual communication settings used for the subnetwork.

| Parameter            | Description                         | Master Mode and Generic Mode                                     |
|----------------------|-------------------------------------|--|
| Bit rate (baud rate) | Selects the bit rate                | 1200<br>2400<br>4800<br>9600<br>19200<br>35700<br>38400<br>57600 |
| Data bits            | Selects the number of data bits     | 7, 8   |
| Parity               | Selects the parity mode             | None, Odd, Even  |
| Physical standard    | Selects the physical interface type | RS232, RS422, RS485  |
| Start bits           | Number of start bits.               | 1  |
| Stop bits            | Number of stop bits.                | 1, 2   |

### Start- and End Character

**Note:** These parameters are only available in Generic Data Mode.

Start and end characters are used to indicate the beginning and end of a serial message. For example, a message may be initiated with <ESC> and terminated with <LF>. In this case, the Start character would be 0x1B (ASCII code for <ESC>) and the End character 0x0A (ASCII code for <LF>)

| Parameter             | Description  | Valid settings   |
|-----------------------|--|------------------|
| End Character Value   | End character for the message, ASCII                   | 0x00 - 0xFF      |
| Use End Character     | Determines if the End character shall be used or not   | Enable / Disable |
| Start Character Value | Start character for the message, ASCII                 | 0x00 - 0xFF      |
| Use Start Character   | Determines if the Start character shall be used or not | Enable / Disable |

### Timing (Message Delimiter)

The parameters in this category differs slightly between the different protocol modes.

- **Master Mode**

The Message Delimiter specifies the time that separates two messages in steps of 10ms. If set to 0 (zero), the gateway will use the standard Modbus delimiter of 3.5 characters (the actual number of ms will be calculated automatically based on the currently used communication settings).

- **Generic Data Mode**

The Message Delimiter specifies the time that separates two messages in steps of 10 $\mu$ s.

## 5. Nodes

### 5.1 General


In Anybus Configuration Manager, a node represents a single device on the network. While the gateway doesn't feature a scanlist in the traditional sense, all nodes, and their transactions, will be processed in the order they have been defined in the Anybus Configuration Manager.

The maximum number of nodes that can be created in the Anybus Configuration Manager is 31.

### 5.2 Adding & Managing Nodes

(Right-click on 'Sub Network' in the Navigation Section to gain access to these functions)

| Function                     | Description   |
|------------------------------|---|
| Paste                        | Paste a node from the clipboard                             |
| Subnetwork Monitor           | Launch the subnet monitor ("Subnetwork Monitor" on page 59) |
| Add Node                     | Add a node to the configuration                             |
| Add Broadcaster <sup>a</sup> | Add a broadcaster node to the configuration                 |
| Load Node                    | Add a previously saved node                                 |
| Subnetwork Status...         | View diagnostic information about the subnetwork            |



a. This function is only available in Master Mode.

### 5.3 Node Parameters

#### 5.3.1 Master Mode and Generic Data Mode

(To gain access to the parameters described in this section, select a node in the Navigation Section).



| Parameter     | Description   |
|---------------|---|
| Slave Address | The value entered here may be used to set the node address in certain commands.<br>For more information, see "The Command Editor" on page 48. |



## 6. Transactions

### 6.1 General

As mentioned previously, transactions are representations of the actual serial telegrams exchanged on the serial subnetwork. While the gateway doesn't feature a scanlist in the traditional sense, all nodes, and their transactions, will be processed in the order they have been defined in the Anybus Configuration Manager.

Transactions are handled slightly differently in the three protocol modes:

- **Master Mode**

For regular nodes, transactions always come in pairs; a query and a response. The query is issued by the gateway, while responses are issued by the slaves on the subnetwork. The Broadcaster can only send transactions.

- **Generic Data Mode**

Transactions can be added as desired for both directions. Transactions sent to the subnetwork are called 'Transaction Produce', and transactions issued by other nodes are called 'Transaction Consume'.

- **DF1 Master Mode**


Please refer to "DF1 Protocol Mode" on page 52.

Theoretically, the gateway supports up to 150 transactions. The actual number may however be less depending on the memory requirements of the defined transactions.

## 6.2 Adding & Managing Transactions

(Right-click on a node in the Navigation Section to gain access to these functions)

| Function                             | Description  |
|--------------------------------------|--|
| Cut                                  | Cut a node to the clipboard  |
| Copy                                 | Copy a node to the clipboard   |
| Insert                               | Insert a node from the clipboard   |
| Delete                               | Delete a node  |
| Node Monitor                         | Launch the node monitor ( "Node Monitor" on page 60)   |
| Add Transaction(s) <sup>a</sup>      | On regular nodes, this adds a Query and a Response.<br>The two transactions will be grouped in order to increase readability.<br>On the Broadcaster, a single transaction will be added. |
| Add Transaction Consume <sup>b</sup> | Add a 'Consume'-transaction  |
| Add transaction Produce <sup>b</sup> | Add a 'Produce'-transaction  |
| Add Command                          | Add predefined transactions to the node  |
| Insert New Node                      | Insert a new node above the currently selected one   |
| Save Node                            | Save the selected node   |
| Insert from File                     | Insert a previously saved node above the currently selected node   |
| Rename                               | To increase readability, each node can be given a unique name using this function  |



a. Only available in Master Mode

b. Only available in Generic Data Mode

## 6.3 Transaction Parameters (Master Mode)

### 6.3.1 Parameters (Query & Broadcast)

(To gain access to these parameters, select a Query- or Broadcast- transaction in the Navigation Section)

| Parameter                               | Description   |
|---|---|
| Minimum time between broadcasts (10 ms) | <p>This parameter specifies how long the gateway shall wait after transmitting a broadcast transaction before processing the next entry in the scanlist. The value should be set high enough to allow the slave devices time to finish the handling of the broadcast.</p> <p>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.</p> <p><b>Note:</b> This setting is only relevant for the Broadcaster node.</p>   |
| Offline options for field-bus           | <p>This parameter specifies the action to take for this transaction if the higher level network goes offline. This affects the data that is sent to the subnetwork.</p> <ul style="list-style-type: none"> <li>• <b>Clear</b> - The data destined for the slave-devices is cleared (set to zero)</li> <li>• <b>Freeze</b> - The data destined for the slave-device is frozen</li> <li>• <b>NoScanning</b> -The updating of the subnetwork is stopped</li> </ul>   |
| Offline options for sub-network         | <p>This parameter specifies the action to take for this transaction if the subnetwork goes offline. This affects the data that is reported to the control system.</p> <ul style="list-style-type: none"> <li>• <b>Clear</b> - Data is cleared (0) on the higher level network if the subnetwork goes offline</li> <li>• <b>Freeze</b> - Data is frozen on the higher level network if the subnetwork goes offline</li> </ul>  |
| Reconnect time (10 ms)                  | <p>This parameter specifies how long the gateway shall wait before attempting to reconnect a disconnected node. A node will be disconnected in case the maximum number of retries (below) has been reached.</p> <p>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.</p> <p><b>Note:</b> This setting is not relevant for the Broadcaster node.</p>  |
| Retries                                 | <p>This parameter specifies how many times a timeout may occur in sequence before the node is disconnected.</p>   |
| Timeout time (10 ms)                    | <p>This parameter specifies how long the gateway will wait for a response from a node. If this time is exceeded, the gateway will retransmit the Query until the maximum number of retries (see above) has been reached.</p> <p>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.</p>  |
| Trigger byte address                    | <p>This parameter specifies the location of the trigger byte in internal memory (only relevant when 'Update mode' is set to 'Change of state on trigger').</p> <p>Valid settings range from 0x200... 0x3FF and 0x400... 0xNNN</p>   |
| Update mode                             | <p>This parameter is used to specify when the transaction shall be sent to the slave:</p> <ul style="list-style-type: none"> <li>• <b>Cyclically</b><br/>The transaction is issued cyclically at the interval specified in the 'Update time' parameter.</li> <li>• <b>On data change</b><br/>The data area is polled for changes at the time interval defined by Update time. A transaction is issued when a change in data is detected.</li> <li>• <b>Single shot</b><br/>The Query is issued once at start up.</li> <li>• <b>Change of state on trigger</b><br/>The Query is issued when the trigger byte value has changed. This feature enables the control system to notify the gateway when to issue a particular Query. To use this feature correctly, the control system must first update the data area associated with the Query/ transaction, then increase the trigger byte by one. The location of the trigger byte is specified by the 'Trigger byte address' parameter.</li> </ul> |

---

| Parameter           | Description   |
|---------------------|---|
| Update time (10 ms) | <p>This parameter specifies how often the transaction will be issued in steps of 10 ms (only relevant when 'Update mode' is set to 'Cyclically').</p> <p>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.</p> |

## 6.3.2 Parameters (Response)

(To gain access to these parameters, select a Response-transaction in the Navigation Section)

| Parameter            | Description   |
|----------------------|---|
| Trigger byte         | This parameter is used to enable/disable the trigger functionality for the response. If enabled, the gateway will increase the trigger byte by one when the gateway receives new data from the subnetwork. This can be used to notify the control system of the updated data.<br>The location of the trigger byte is specified by the 'Trigger byte address' parameter below. |
| Trigger byte address | This parameter specifies the location of the trigger byte in the internal memory buffer.<br>Valid settings range from 0x000... 0x1FF and 0x400... 0xNNN   |

## 6.4 Transaction Parameters (Generic Data Mode)

### 6.4.1 Produce-Transactions

(To gain access to these parameters, select a Produce Transaction in the Navigation Section)

| Parameter                    | Description  |
|------------------------------|--|
| Offline options for fieldbus | This parameter specifies the action to take for this transaction if the higher level network goes offline. This affects the data that is sent to the subnetwork. <ul style="list-style-type: none"> <li>• <b>Clear</b><br/>Data is cleared (0) on the subnetwork if the higher level network goes offline</li> <li>• <b>Freeze</b><br/>Data is frozen on the subnetwork if the higher level network goes offline</li> <li>• <b>NoScanning</b><br/>Stop subnet scanning for this transaction if the higher level network goes offline</li> </ul>  |
| Update mode                  | The update mode for the transaction: <ul style="list-style-type: none"> <li>• <b>Cyclically</b><br/>The transaction is sent cyclically at the interval specified in the 'Update Time'-parameter.</li> <li>• <b>On data change</b><br/>The data area is polled for changes at the time interval defined by Update time. A transaction is issued when a change in data is detected.</li> <li>• <b>Single shot</b><br/>The transaction is sent once at startup.</li> <li>• <b>Change of state on trigger</b><br/>The transaction is sent when the trigger byte has changed. This feature enables the control system to notify the gateway when to issue a particular transaction. To use this feature correctly, the control system must first update the data area associated with the transaction, then increase the trigger byte by one. The location of the trigger byte is specified by the 'Trigger byte address' parameter.</li> </ul> |
| Update time (10 ms)          | This parameter specifies how often the transaction will be issued in steps of 10ms (only relevant when 'Update mode' is set to 'Cyclically').<br>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.  |

| Parameter            | Description  |
|----------------------|--|
| Trigger byte address | <p>This parameter specifies location of the trigger byte in the internal memory buffer.</p> <p>If 'Update mode' is set to 'Change of state on trigger', the memory location specified by this parameter is monitored by the gateway. Whenever the trigger byte is updated, the gateway will produce the transaction on the subnetwork.</p> <p>This way, the control system can instruct the gateway to produce a specific transaction on the subnetwork by updating the corresponding trigger byte.</p> <p>The trigger byte should be incremented by one for each activation. Please note that the trigger byte address must be unique to each transaction. It can not be shared by two or more transactions.</p> <p><b>Note:</b> This parameter has no effect unless the 'Update mode' parameter is set to 'Change of state on trigger'.</p> <p>Valid settings range from 0x200... 0x3FF and 0x400... 0xNNN</p> |


## 6.4.2 Consume-Transactions

(To gain access to these parameters, select a Consume Transaction in the Navigation Section)

| Parameter                      | Description   |
|--------------------------------|---|
| Offline options for subnetwork | <p>This parameter specifies the action to take for this transaction if the subnetwork goes offline. This affects the data that is sent to the higher level network.</p> <ul style="list-style-type: none"> <li>• <b>Clear</b><br/>Data is cleared (0) on the higher level network if the subnetwork goes offline</li> <li>• <b>Freeze</b><br/>Data is frozen on the higher level network if the subnetwork goes offline</li> </ul>  |
| Offline timeout time (10 ms)   | <p>This parameter specifies the maximum allowed time between two incoming messages in steps of 10ms. If this time is exceeded, the subnetwork is considered to be offline. A value of 0 disables this feature, i.e. the subnetwork can never go offline.</p> <p>The entered value is multiplied by 10. For instance, an entered value of 5 results in 50 ms.</p>  |
| Trigger byte                   | <ul style="list-style-type: none"> <li>• <b>Enable</b><br/>Enables the trigger byte. The location of the trigger byte must be specified in the 'Trigger byte address' (below).<br/>The trigger byte value will be increased each time a valid transaction has been consumed by the gateway.<br/>The trigger byte will also be increased if the offline option is set to "Clear" and the offline timeout time value is reached.<br/>This feature enables the control system to be notified each time new data has been consumed on the subnetwork.</li> <li>• <b>Disable</b><br/>Disables the trigger byte functionality.</li> </ul> |
| Trigger byte address           | <p>This parameter specifies the location of the trigger byte in the internal memory buffer.</p> <p>Valid settings range from 0x000... 0x1FF and 0x400... 0xNNN.</p> <p>Please note that the trigger byte address must be unique to each transaction. It can not be shared by two or more transactions.</p>  |


## 6.5 Transaction Editor

The Transaction Editor can be used to edit the individual frame objects of a transaction. The same settings are also available in the parameter section of the main window, however the Transaction Editor presents the frame objects in a more visual manner.




To edit the value of a parameter, click on it and enter a new value using the keyboard. When editing transactions which are based on predefined commands, certain parts of the transaction may not be editable.

The File menu features the following entries:



- **Apply Changes**  
This will save any changes and exit to the main window.
- **Exit**  
Exit without saving.

*Example:*



The transaction created in this example are built up as follows:

The first byte holds the STX (0x02) followed by two bytes specifying the length of the data field (in this case 8). The next 8 bytes are data and since this is a 'query'-transaction, the data is to be fetched from the Output Area which starts at address location 0x202. No swapping will be performed on the data. This is followed by a two-byte checksum. The checksum calculation starts with the second byte in the transaction.

The transaction ends with a byte constant, the ETX (0x03).

## 7. Frame Objects

### 7.1 General


Each transaction consists of Frame Objects which makes up the serial telegram frame. Each Frame Object specifies how the gateway shall interpret or generate a particular part of the telegram.

There are 5 types of frame objects, which are described in detail later in this chapter:

- Constant Objects
- Limit Objects
- Data Objects
- Variable Data Objects
- Checksum Objects

*Example:*



The following Transaction consists of several frame objects; three constants, a data object, and a checksum object.



### 7.2 Adding and Editing Frame Objects

To add a frame object to a Transaction, right-click on the Transaction in the Navigation Section and select one of the entries in the menu that appears.

The entry called 'Transaction Editor' will launch the Transaction Editor, which is used to edit transactions and frame objects in a more visual manner. For more information, see "Transaction Editor" on page 39.



**Data Object, Parameters**

To edit parameters associated with a particular frame object, select the frame object in the Navigation Section. The settings for that frame object will be displayed in the Parameter Section.

It is also possible to edit the frame objects in a transaction in a more visual manner using the Transaction Editor, see "Transaction Editor" on page 39



## 7.3 Constant Objects (Byte, Word, Dword)

Constant Objects have a fixed value and come in three sizes:

- **Byte**  
8 bits
- **Word**  
16 bits
- **Dword**  
32 bits

Constants are handled differently depending on the direction of the transaction:

- **Produce/Query Transactions**  
The gateway will send the value as it is without processing it.
- **Consume/Response Transactions**  
The gateway will check if the received byte/word/dword matches the specified value. If not, the message will be discarded.

To set the value of the object, select it in the Navigation Section and enter the desired value in the Parameter section.

| Parameter | Description    |
|-----------|----------------|
| Value     | Constant value |

## 7.4 Limit Objects (Byte, Word, Dword)

Limit Objects have a fixed range and come in three sizes:

- **Byte**  
8 bits
- **Word**  
16 bits
- **Dword**  
32 bits

Limit Objects are handled differently depending on the direction of the transaction:

- **Produce/Query Transactions**  
This object shall not be used for such transactions (value will be undefined).
- **Consume/Response Transactions**  
The gateway will check if the received byte/word/dword fits inside the specified boundaries. If not, the message will be discarded.

There are 3 types of interval objects:

- **Byte**  
8 bit interval
- **Word**  
16 bit interval
- **Dword**  
32 bit interval

To set the range of the object, select it in the Navigation Section and enter the desired range in the Parameter section as follows:

| Parameter     | Description  |
|---------------|--|
| Maximum Value | This is the largest allowed value for the range.<br>Range:0x00... 0xFFh(byte)<br>0x0000... 0xFFFFh(word)<br>0x00000000... 0xFFFFFFFFh(dword)<br><b>Note:</b> Value must be larger than the Minimum Value (below) |
| Minimum Value | This is the smallest allowed value for the range.<br>Range:0x00... 0xFEh(byte)<br>0x0000... 0xFFEh(word)<br>0x00000000... 0xFFFFFEEh(dword)<br><b>Note:</b> Value must be less than the Maximum Value (above)    |

## 7.5 Data Object

Data Objects are used to represent raw data as follows:

- **Produce/Query Transactions**  
The specified data block is forwarded from the higher level network to the subnetwork.
- **Consume/Response Transactions**  
The specified data block is forwarded from the subnetwork to the higher level network.


To specify the properties of the object, select it in the Navigation Section and enter the desired settings in the Parameter section as follows:

| Parameter     | Description   |
|---------------|---|
| Byte Swapping | <ul style="list-style-type: none"> <li>• <b>No Swapping</b><br/>No swapping is performed on the data</li> <li>• <b>Swap 2 bytes</b><br/>A, B, C, D becomes B, A, D, C</li> <li>• <b>Swap 4 bytes</b><br/>A, B, C, D becomes D, C, B, A</li> </ul> |
| Data Length   | The length of the data block, in bytes. In case of a Response or Consume transaction, incoming messages where the data size differs from the value specified here will be discarded. Maximum data length allowed for one frame is 300 bytes.      |
| Data Location | The location of the data block in the internal memory buffer  |

## 7.6 Variable Data Object

**Note:** Only one Variable Data Object is permitted for each transaction.

This object is similar to the Data Object, except that it has no predefined length. Instead, an End or Length-character specifies the size of the data block as follows:



- **Produce/Query Transactions**  
The specified data block will be forwarded from the higher level network to the subnetwork. The control system must supply an End- or Length-character in order for the gateway to know the size of the data block.  
The End- or Length-character itself may either be forwarded to the subnetwork or discarded.
- **Consume/Response Transactions**  
The specified data block is forwarded from the subnetwork to the higher level network. The End- or Length-character will be generated by the gateway automatically (if applicable).  
The End- or Length-character itself may either be forwarded to the higher level network or discarded.

To specify the properties of the object, select it in the Navigation Section enter the desired settings in the Parameter section as follows:

| Parameter           | Description   |
|---------------------|---|
| Byte Swapping       | <ul style="list-style-type: none"> <li>• <b>No Swapping</b><br/>No swapping will be performed on the data</li> <li>• <b>Swap 2 bytes</b><br/>A, B, C, D becomes B, A, D, C</li> <li>• <b>Swap 4 bytes</b><br/>A, B, C, D becomes D, C, B, A</li> </ul>  |
| Fill unused bytes   | <ul style="list-style-type: none"> <li>• <b>Enabled<sup>a</sup></b><br/>Fill unused data with the value specified in 'Filler byte'.</li> <li>• <b>Disabled</b><br/>Don't fill</li> </ul>  |
| Filler byte         | Filler byte value. Only used if 'Fill unused bytes' has been enabled.   |
| Data Location       | The offset in the internal memory buffer where the data shall be read from / written to   |
| Object Delimiter    | <ul style="list-style-type: none"> <li>• <b>Length Character</b><br/>Length character is visible in the internal memory buffer but <i>not</i> on the subnetwork</li> <li>• <b>Length Character Visible</b><br/>The length character is visible both in the internal memory buffer <i>and</i> on the subnetwork.</li> <li>• <b>End Character</b><br/>The end character is visible in the internal memory buffer but <i>not</i> on the subnetwork.</li> <li>• <b>End Character Visible</b><br/>The end character is visible both in the internal memory buffer <i>and</i> on the subnetwork</li> <li>• <b>No Character<sup>a</sup></b><br/>No End- or Length-character is generated in the internal memory buffer.</li> </ul> |
| End Character Value | End Character value <sup>b</sup>  |
| Maximum Data Length | The maximum allowed length (in bytes) of the variable data object. If the actual length of the data exceeds this value, the message will be discarded. The value must not exceed 300 bytes, which is the maximum data length allowed for one frame.   |

a. Only relevant for Consume/Response transactions

b. Only used if 'Object Delimiter' is set to 'End Character' or 'End Character Visible'

## 7.7 Checksum Object

Most serial protocols features some way of verifying that the data has not been corrupted during transfer. The Checksum Object calculates and includes a checksum in a transaction.

| Parameter              | Description   |
|------------------------|---|
| Error Check Start byte | This parameter specifies the byte offset in the transaction to start checksum calculations on   |
| Error Check Type       | <p>This parameter specifies which type of algorithm to use:</p> <ul style="list-style-type: none"><li>• <b>CRC (2 bytes)</b><br/>CRC-16 with 0xA001 polynome (Modbus RTU standard)</li><li>• <b>LRC (1 byte)</b><br/>All bytes are added together as unsigned 8-bit values. The 2's complement of the result will be used as a checksum.</li><li>• <b>XOR (1 byte)</b><br/>All bytes are logically XOR:ed together. The resulting byte will be used as a checksum.</li><li>• <b>ADD (1 byte)</b><br/>All bytes are added together as unsigned 16-bit values. The lowest 8 bits in the result will be used as a checksum.</li><li>• <b>AddInvASCII (2 bytes)</b><br/>All bytes are added together as unsigned 8-bit values. The lowest 8 bits in the result are inversed and used as a checksum, represented as hexadecimal ASCII (2 bytes).</li></ul> |

## 8. Commands

This information is only valid for master mode and generic mode. For DF1 master mode, please refer to “Services” on page 55.

### 8.1 General

As mentioned previously, commands are actually predefined transactions that can be stored and reused. Just like regular transactions, commands consist of frame objects and are representations of the actual serial telegrams exchanged on the serial subnetwork.


Adding a command to a node actually results in (a) transaction(s) being added according to the directions specified in the command. The frame objects in such a transaction may retrieve their values not only from parameters in the parameter section, but also from other sources such as the ‘SlaveAddress’-parameter (see “Node Parameters” on page 32). In such case, the parameters in the parameter section will be greyed out and cannot be edited directly.

In Master Mode, Anybus Configuration Manager comes preloaded with commands for most common Modbus RTU functions. Additional commands can easily be added using the Command Editor (see “The Command Editor” on page 48). For DF1 Master Mode, see “Services” on page 55. In Generic Data Mode, no predefined commands exist, but custom ones may be implemented as desired.

### 8.2 Adding & Managing Commands

To add a command to a node, right-click on the node in the Navigation Section and select ‘Add Command’.

A list of commands will appear:



Select the desired command in the list, and select ‘Add Command’ in the ‘Command’-menu. The specified command will be added to the node.


Just like other transactions, the frame objects of added command may be edited in the Navigation/Parameter Section or using the Transaction Editor. Note however that certain frame objects may be locked for editing.

## 8.2.1 Pull-Down Menu

### File

This menu features the following entries:


- **Select**  
Add the currently selected Command to the node.
- **Exit**  
Exit without adding a command to the node.



### Command

This menu is used to manage the commands in the list:

- **Add Command**  
Add a custom command to the list, and open the new command in the Command Editor.  
See also “The Command Editor” on page 48.
- **Edit Command**  
Edit the currently selected command using the Command Editor.  
See also “The Command Editor” on page 48.
- **Delete Command**  
Delete the currently selected command from the list. Note that some commands are fixed and cannot be deleted.



## 8.2.2 Toolbar Icons

The toolbar features icons for the most commonly used functions.

- **Add Command**  
(Same as ‘Add Command’ in the ‘Command’-menu).
- **Edit Command**  
(Same as ‘Edit Command’ in the ‘Command’-menu).
- **Delete Command**  
(Same as ‘Delete Command’ in the ‘Command’-menu).



Add Command



Edit Command



Delete Command

## 8.3 The Command Editor

### 8.3.1 General


The Command Editor is used to define new commands and edit existing ones. This makes it possible to build a library of commands, which can be stored and reused at a later stage.

Note that the Command Editor is somewhat protocol-dependent in the sense that certain frame objects may not be deleted or altered.

The examples in this section use Master Mode. The procedures involved are similar in Generic Data Mode, but without the limitations imposed by the Modbus RTU protocol.

### 8.3.2 Basic Navigation

Open the Command Editor by selecting 'Edit Command' or 'Add Command' from the 'Command'-menu.



#### A: Pull-down Menu

See "Pull-down Menu" on page 49.

#### B: Name of Command

Actual name of the command, in text form.

#### C: Command Transactions

This section holds the actual transactions associated with the command. This can either be a query-response pair, or a single transaction, depending on the protocol mode etc.

#### D: Command ID

This can be used as desired when building the command, e.g. to specify the function code.

#### E: Other Settings

| Setting            | Description  |
|--------------------|--|
| Allow Broadcasting | Specifies if it is allowed to broadcast the command (only relevant in Master Mode) |
| Produce            | The command is producing data (Generic Data Mode only)                             |
| Consume            | The command is consuming data (Generic Data Mode only)                             |




### 8.3.3 Pull-down Menu

#### File

This menu features the following entries:


- **Apply Changes**  
Save changes and exit to the main window.
- **Exit**  
Exit without saving.



#### Column

The functions in this menu alters the structure of the command.

- **Append Column**  
Add another column to the command.
- **Insert Column**  
Insert a column at the selected position.
- **Delete Command**  
Delete the column at the selected position.



### 8.3.4 Editing a Command

As mentioned previously, the transaction section in the Command Editor represents the actual transactions associated with the command. Each column represents a frame object within the transaction.

Each column features four rows with the following parameters:

- **Query/Response/Produce/Consume**  
The upper right cell indicates the direction of the transaction.
- **DisplayName**  
Each column can be named so that the different parts of the command appears in a more user friendly manner when editing its settings in the Transaction Editor or in the Parameter Section of the Main Window.
- **ObjectType**  
This row specifies the type of frame object that shall be used for the column.
- **Value**  
This row specifies where the frame object shall retrieve its value/settings.

| Value            | Description  |
|------------------|--|
| Depend           | This setting is only relevant for Responses in Master Mode.<br>The value will be retrieved from the corresponding part of the 'Query'-transaction. |
| Id               | The value will be retrieved from the 'Command ID'-setting (see "Basic Navigation" on page 48).   |
| User             | The settings associated with the object can be edited by the user.   |
| [SlaveAddress]   | The value will be retrieved from the 'SlaveAddress'-parameter (see "Node Parameters" on page 32).  |
| (other settings) | Other settings are no longer supported.  |

### 8.3.5 Example: Specifying a Modbus-RTU Command in Master Mode

In the following example, a Modbus-RTU command is created in Master Mode. In Modbus-RTU, a transaction always feature the following parts:

- Slave Address (1 byte)
- Function Code (1 bytes)
- A data field
- CRC (CRC-16)

Furthermore, each command always consists of a query and a response.

- **Example Query**

| Query       | 1  | 2   | 3  | 4  |
|-------------|--|---|--|--|
| DisplayName | Slave Address  | Function  | Data   | Checksum   |
| Object Type | Byte Object  | Byte Object   | Data Object  | Checksum Object  |
| Value       | [SlaveAddress]   | ID  | User   | User   |
|             | The value of this byte constant will be set using the 'SlaveAddress' parameter (see "Node Parameters" on page 32). | The value of this byte constant will be set using the 'Command ID'-field. | The size and location of the data associated with this object is determined by the user. | The checksum type etc can be selected by the user. By default, this is set to match the Modbus-RTU standard. |

- **Example Response**

| Response    | 1   | 2   | 3  | 4  |
|-------------|---|---|--|--|
| DisplayName | Slave Address   | Function  | Data   | Checksum   |
| Object Type | Byte Object   | Byte Object   | Data Object  | Checksum Object  |
| Value       | [SlaveAddress]  | ID  | User   | Depend   |
|             | This value is linked to the 'SlaveAddress' parameter in the parameter window. | The value of this byte constant will be set using the 'Command ID'-field. | The size and location of the data associated with this object is determined by the user. | This object will retrieve its settings from the corresponding object in the Query. |

By default, the Modbus-RTU-specific frame objects are already in place, and a data object is inserted between the function code and the CRC. These objects cannot be moved or deleted, however it is possible to add additional objects between the function code and the CRC as desired.

Name the new command by entering its name in the 'Command Name'-field, and enter a suitable function code in the 'Command ID'-field. If the command is allowed to be broadcasted, check the 'Allow Broadcasting'-checkbox.


## 9. DF1 Protocol Mode

This mode makes it possible to let the Anybus Communicator act as a DF1 protocol master on the subnetwork.

### 9.1 General

In DF1 master mode, communication is based on ‘services’. A ‘service’ represents a set of commands and operations on the subnetwork, that is predefined in the Anybus Communicator. Each service is associated with a set of parameters controlling how and when to use it on the subnetwork.

The communication is based on a query-response scheme, where the gateway issues a query on the subnetwork. The addressed node on the subnetwork is expected to issue a response to that query. Nodes are not permitted to issue responses spontaneously, i. e. without first receiving a query.



In DF1 Master Mode, Anybus Configuration Manager comes preloaded with a number of services, that can be selected by the user. The actual DF1 commands, that perform the services during runtime, are predefined in the Anybus Communicator. The configuration of the services is performed by right-clicking on a node in the Anybus Configuration Manager and selecting ‘Add Command’.

## 9.2 ABC Parameters

(Select 'ABC' in the Navigation Section to gain access to the parameters described in this section).



### Interface

Currently, only serial communication is supported.

### Status / Control Word

(See "Control and Status Registers" on page 68).

| Value                       | Description   |
|-----------------------------|---|
| Enabled                     | Enable the Control and Status Registers. The 'Data Valid'-bit in the Control Register must be set to start the subnetwork communication.                |
| Enabled but no startup lock | This setting is similar to 'Enabled', except that the control system is not required to set the 'Data Valid'-bit to start the subnetwork communication. |
| Disabled                    | This setting completely disables the Control and Status Registers.  |

### Module Reset

This parameter specifies how the gateway will behave in the event of a fatal error.

| Value    | Description  |
|----------|--|
| Enabled  | The gateway will be restarted, and no error will be indicated to the user. |
| Disabled | The gateway will halt and indicate an error.                               |

### Protocol Mode

This parameter specifies which protocol mode to use for the subnetwork.

| Value | Description  |
|-------|--|
| DF1   | This mode is intended for the DF1 protocol. The Anybus Communicator can only be configured as a Master with half-duplex communication.<br><b>Note:</b> This is the only mode available if you intend to configure an ABC module for DF1. |

See also "Protocol Modes" on page 18.

### Statistics

The Transmit- and Receive Counters indicate how many transactions that have successfully been exchanged on the subnetwork. This feature is primarily intended for debugging purposes.

- **Receive Counter Location**  
Specifies the location of the Receive Counter in the internal memory buffer.
- **Transmit Counter Location**  
Specifies the location of the Transmit Counter in the internal memory buffer.

Both counters are enabled by setting 'Statistics' to 'Enabled'.

## 9.3 Subnetwork Parameters

(To gain access to the parameters described in this section, select 'Subnetwork' in the Navigation Section).



### Communication

These parameters specify the actual communication settings used for the subnetwork.

| Parameter            | Description                         | Valid Settings                                   |
|----------------------|-------------------------------------|--|
| Bit rate (baud rate) | Selects the bit rate                | 2400<br>4800<br>9600<br>19200<br>38400 (Default) |
| Data bits            | Selects the number of data bits     | 8  |
| Parity               | Selects the parity mode             | None, Odd, Even                                  |
| Physical standard    | Selects the physical interface type | RS232, RS422, RS485                              |
| Start bits           | Number of start bits.               |  |
| Stop bits            | Number of stop bits.                | 1  |



### DF1 Settings

| Parameter                          | Description  |
|------------------------------------|--|
| Master Node Address                | Node address of the master, valid values: 0 - 254, default 1                                   |
| Poll time, active slaves (10 ms)   | Determines how often the slave shall be polled in steps of 10 ms, default 100 ms <sup>a</sup>  |
| Poll time, inactive slaves (10 ms) | Determines how often the slave shall be polled in steps of 10 ms, default 1000 ms <sup>b</sup> |

- a. The default value is given as 10 in the parameter window. Each change of 10 ms either increases or decreases this value by 1, i.e. 9 represents a poll time of 90 ms and 11 represents a poll time of 110 ms.
- b. The default value is given as 100 in the parameter window. Each change of 10 ms either increases or decreases this value by 1, i.e. 99 represents a poll time of 990 ms and 101 represents a poll time of 1010 ms.

## 9.4 Node Parameters

To gain access to the parameters described in this section, select a node in the navigation section. For more information about nodes, see “Nodes” on page 32.



| Parameter     | Description                                   | Valid Settings                |
|---------------|---|-------------------------------|
| Checksum      | Selects the type of checksum on the network.  | BCC<br>CRC (default)          |
| Slave Address | The value entered here sets the node address. | 0-254                         |
| Type          | The PLC type of the slave                     | PLC-5<br>SLC500<br>MicroLogix |

## 9.5 Services

Services are commands that can be stored and reused. The user configures each slave with services that can be issued from the master. A total of 50 services are allowed.

The Anybus Communicator supports a selection of DF1 commands. When the gateway is going to execute a service, it automatically chooses the appropriate DF1 command(s) that are used to perform the service on the selected DF1 node type.


## 9.5.1 Available Services

Right click on the node, and choose Add Command. A pop-up window will show the four different services that are available:

- Integrity check
- Read diagnostics
- Read data
- Write data

A maximum of 50 services in total (for all nodes) can be selected.

The predefined services can be configured to suit the application. Select a service to show the parameters.




### General Configuration Parameters

These parameters are common to all services, but the settings are individual to each instance of a service.

#### General:

| Parameter                      | Description   | Valid settings  |
|--------------------------------|---|---|
| Offline options for fieldbus   | The action to take for this service if the fieldbus goes offline. This option affects the data that is sent out to the subnetwork.        | Clear<br>Freeze<br>Noscanning   |
| Offline options for subnetwork | The action to take for this service if the subnetwork goes offline. This option affects the data that is reported to the fieldbus master. | Clear<br>Freeze   |
| Update mode                    | The update mode for this service  | Cyclically<br>On data change<br>Single shot<br>Change of state on trigger |



#### Timing:

| Parameter            | Description   | Default |
|----------------------|---|---------|
| Retries              | The number of times to resend this service before the node is disconnected          | 3       |
| Timeout time (10 ms) | The time to wait before resending this service (in steps of 10 ms) <sup>a</sup>     | 1000 ms |
| Update time (10 ms)  | The minimum time between two services of this kind (in steps of 10 ms) <sup>a</sup> | 1000 ms |

a. The default value is given as 100 in the parameter window. Each change of 10 ms either increases or decreases this value by 1, i.e. 99 represents a poll time of 990 ms and 101 represents a poll time of 1010 ms.

#### Trigger:

| Parameter                     | Description  | Default  |
|-------------------------------|--|----------|
| Request Trigger byte address  | The memory location of the trigger byte this service uses for updates on trigger byte changes  | 0x05FF   |
| Response Trigger byte         | Enables/disables the trigger byte  | Disabled |
| Response Trigger byte address | The memory location of the trigger byte this service uses for updates on trigger byte changes<br>Valid settings range from 0x200... 0x3FF and 0x400... 0xNNN | 0x05FF   |




## 9.6 Integrity Check

This service checks that a node is up and running correctly. A telegram is sent to the node. The node mirrors and returns the telegram. No configuration is needed, apart from the general parameters, common to all services.

## 9.7 Read Diagnostics

This service reads diagnostic information from the module.



### Command parameters

The command parameter Size decides the amount of data that can be read. The size is given in bytes which means that it always has to be an even number as only whole elements can be read from the slave. One bit/integer element is 2 bytes and one float element is 4 bytes. The range of the size differs, depending on node type:


|                              | PLC-5 | SLC500 | MicroLogix |
|------------------------------|-------|--------|------------|
| <b>Size range (in bytes)</b> | 1-26  | 1-28   | 1-26       |

### Data options:

| Parameter   | Description   | Valid settings                                  |
|-------------|---|---|
| Byte swap   | Determines if the data shall be swapped   | No byte swap<br>Swap words<br>Swap double words |
| Data length | The number of bytes, read from the DF1 network, to write to the area determined by the Offset parameter           | ≤ Size  |
| Offset      | The offset in the internal memory buffer in the module, where the data shall be read. See "Memory Map" on page 16 |   |

## 9.8 Read Data

This service is used to read data from the nodes in the subnetwork.



### Command Parameters

| Parameter      | Description   | Valid settings   |
|----------------|---|--|
| Element Number | The element number of the data file to be accessed within the slave.  | PLC-5: 0-999<br>SLC500: 0-255<br>MicroLogix: 0-255                               |
| File number    | The file number of the data file to be accessed.  | PLC-5: 3, 7, 8, 10-999<br>SLC500: 3, 7, 8, 10-255<br>MicroLogix: 3, 7, 8, 10-255 |
| File type      | The file type of the data to be accessed.   | Integer<br>Bit<br>Float  |
| Size           | The number of bytes to read from the slave. One bit/integer element is 2 bytes and one float element is 4 bytes. The parameter must have an even value as only whole elements can be read from the slave. | PLC-5: 2-240<br>SLC500: 2-236<br>MicroLogix: 2-242                               |

### Data Options

| Parameter   | Description   | Valid settings                                  |
|-------------|---|---|
| Byte swap   | Determines if the data shall be swapped.  | No byte swap<br>Swap words<br>Swap double words |
| Data length | The number of bytes, read from the DF1 network, to write to the area determined by the Offset parameter   | ≤ Size  |
| Offset      | The offset in the internal memory buffer in the module, where the data shall be read. See "Memory Map" on page 16.<br><b>Note:</b> If the control and status registers are enabled (default), first available data location will be: Input area 0x002, Output area 0x202. | -   |

## 9.9 Write Data

This service is used to write data to the nodes in the subnetwork. The parameters to be configured are the same as for the service Read Data. The only difference is that data is read from the internal memory buffer in the Anybus Communicator and written to the subnetwork bus, instead of being written to the internal memory buffer.

## 10. Subnetwork Monitor


### General

The Subnetwork Monitor is intended to simplify configuration and troubleshooting of the subnetwork. Its main function is to display the data allocated for subnetwork communication and detect if any area has been allocated twice (i.e if a collision has occurred).

All configured nodes, and their transactions, are listed in the middle of the screen (B). Selecting and de-selecting single transactions makes it possible to view any combination of allocated data.

**Note:** The subnetwork monitor has a negative influence on the overall performance of the gateway. Therefore the monitor functionality should be used with care.

### Operation



#### A: Start Network & Stop Network Icons

These icons controls the subnetwork activity. To stop all subnetwork activity, click on the red light. To start the subnetwork again, click on the green light.



#### B: Nodes / Transactions

To view data blocks associated with a transaction, select the transaction in the list. The corresponding data will then appear in the Monitor Section (C).

#### C: Monitor Section

This section visualizes how data is allocated in the Input, Output and General Data areas.

| Color  | Meaning  |
|--------|--|
| White  | Not allocated.   |
| Yellow | Data allocated by a Response or Consume transaction.                                   |
| Blue   | Data allocated by a Query or Produce transaction                                       |
| Red    | Collision; area has been allocated more than once.                                     |
| Grey   | Reserved (illustrates memory consumption, area can be allocated if necessary)          |
| Green  | Data allocated by Trigger byte, Transmit/Receive Counter, or Control/Status Registers. |

# 11. Node Monitor

## 11.1 General


The Node Monitor can provide valuable information when setting up the communication with the subnetwork, by allowing individual commands to be issued manually, and monitoring the response (if applicable). It also provides an overview of the memory used by a particular node.

**Note:** The node monitor has a negative influence on the overall performance of the gateway, i.e. it should be used only when necessary.

The Node Monitor behaves somewhat differently in the three protocol modes:


- **Master Mode and DF1 Master Mode**

The selected Command (Query Transaction) or Service is sent to the subnetwork. The response to the Query can be monitored in the Response Section.




- **Generic Data Mode**

The selected command (Transaction Produce) is sent to the subnetwork. It is not possible to monitor any responses etc. generated by other nodes.



## 11.2 Navigating the Node Monitor



### A: Pull-down Menu & Toolbar Icons

See “Pull-Down Menu” on page 62 and “Toolbar Icons” on page 63.

### B: Command Section

This section holds the currently selected command. The individual frame objects in the command can be edited in a similar way as in the Transaction and Command Editors.

### C: Response Section (Master Mode and DF1 Master Mode only)

This section holds the response to the selected Command.

### D: Monitor Section

This section displays the data associated with the node. Areas in dark grey are reserved for the Status & Control Registers, and areas displayed in light grey represent the data that is used by the node.

The data displayed in this section will be refreshed based on the refresh-icons in the toolbar. For more information, see “Toolbar Icons” on page 63.


## 11.2.1 Pull-Down Menu

### File

There is only one entry in this menu:

- **Exit**

This will close the Node Monitor. Note however that if the node has been disabled using ‘Stop Node’ (see below), it will not resume data exchange until enabled again using ‘Start node’.



### Node


This menu controls the data exchange for the node. This feature can help isolate problems associated with a particular node.

- **Start Node**

Enable the transactions associated with the node.

- **Stop Node**

Disable the transactions associated with the node.



### Command


This menu is used to specify and issue a command manually.

- **Select Command**

Select a command to be sent to the subnetwork.

- **Send Command**

Send the specified command to the subnetwork.



### Columns

This menu specifies the number of columns in the Monitor Section.

- **Free**

The number of columns depends on the width of the window.

- **8 Multiple**

The number of columns will be fixed to 8.



### View


This menu specifies the data representation in the Monitor Section.

- **Hex**

Display the data in hexadecimal format.

- **Decimal**

Display the data in decimal format.



## 11.2.2 Toolbar Icons

The toolbar features icons for the most commonly used functions.

- **Start Node & Stop Node**

These icons corresponds to the functions in the 'Node'-menu.

See also "Node" on page 62.



Start



Stop

- **Select Command & Send Command**

These icons corresponds to the functions in the 'Command'-menu.

See also "Command" on page 62.



Select



Send

- **Resume Refresh & Stop Refresh**

When enabled, the data displayed in the Monitor Section will be re-freshed cyclically. When disabled, i.e. stopped, the data will have to be refreshed manually using the 'Refresh'-icon (see below).



Stop



Resume

- **Refresh**

When clicking on this icon, the data displayed in the Monitor Section will be re-freshed.



Refresh

## 12. Data Logger

### 12.1 General

This feature allows the subnetwork traffic to be logged into a buffer for examination. This may provide valuable information when debugging the lowest levels of the subnetwork communication.

Note that the logger function is part of the gateway itself and is separate from the Anybus Configuration Manager. This means that logging can be performed even if the gateway is physically disconnected from the PC running the Anybus Configuration Manager.

### 12.2 Operation


#### Start & Stop Logging

- **Start logging**  
Select 'Start Logging' in the 'Tools'-menu. Anybus Configuration Manager will then prompt for the desired mode of operation, see below.
- **Stop logging**  
Select 'Stop Logging' in the 'Tools'-menu. This will open the log-window, see below.

#### Modes of Operation

Select the desired mode of operation and click 'OK' to start logging data.

- **Log until full**  
Data will be logged until the log-buffer is full.
- **Log continuously**  
Data will be logged continuously until logging is stopped by clicking 'Stop Logging'. The log-buffer will contain the most recent data.



#### Log Window

The logged data is displayed in hexadecimal, decimal and ASCII format for both directions. The time between the log-entries is displayed in a separate column.

The data may optionally be saved in ASCII text format by clicking 'Create Text file'.

Click 'Close' to exit.

| Line # | Relative Time [ms] | Hex  | Dec | ASCII | Hex  | Dec | ASCII |
|--------|--------------------|------|-----|-------|------|-----|-------|
| 1      | 0                  |      |     |       | 0x6A | 10  | I     |
| 2      | 0                  |      |     |       | 0x03 | 3   | I     |
| 3      | 1                  |      |     |       | 0x00 | 0   |       |
| 4      | 0                  |      |     |       | 0x00 | 0   |       |
| 5      | 1                  |      |     |       | 0x00 | 0   |       |
| 6      | 1                  |      |     |       | 0x01 | 1   | I     |
| 7      | 0                  |      |     |       | 0x05 | 5   | I     |
| 8      | 1                  |      |     |       | 0x71 | 113 | q     |
| 9      | 4                  | 0x04 | 4   |       |      |     |       |
| 10     | 1                  | 0x03 | 3   |       |      |     |       |
| 11     | 0                  | 0x02 | 2   |       |      |     |       |
| 12     | 1                  | 0x00 | 0   |       |      |     |       |
| 13     | 1                  | 0x00 | 0   |       |      |     |       |
| 14     | 0                  | 0x10 | 16  |       |      |     |       |
| 15     | 1                  | 0x05 | 5   |       |      |     |       |
| 16     | 6                  |      |     |       | 0x6A | 10  | I     |
| 17     | 0                  |      |     |       | 0x10 | 16  | I     |
| 18     | 1                  |      |     |       | 0x01 | 1   | I     |
| 19     | 1                  |      |     |       | 0x00 | 0   |       |
| 20     | 0                  |      |     |       | 0x00 | 0   |       |
| 21     | 1                  |      |     |       | 0x01 | 1   | I     |
| 22     | 0                  |      |     |       | 0x02 | 2   | I     |
| 23     | 1                  |      |     |       | 0x00 | 0   |       |




## 12.3 Configuration

By default, the log-buffer can hold 512 bytes of data in each direction. To specify a different size for the buffer, select 'Options' in the 'Tools'-menu.

A window with various settings will appear. Select the 'ABC'-tab, and enter the desired number of buffer entries under 'Size of logbuffer' (valid settings range from 1...512).

Click 'Apply' to validate the new settings.

Click 'OK' to exit.



## 13. Configuration Wizards

### 13.1 General

When creating a new subnetwork configuration, the Anybus Configuration Manager provides a choice between starting out with a blank configuration, or using a predefined template, a.k.a a wizard.


The wizard automatically creates a subnetwork configuration based on information supplied by the user, i.e the user simply has to “fill in the blanks”. Note however that this will only work when the subnetwork fits the wizard profile; in all other cases the ‘Blank Configuration’ option must be used.

### 13.2 Selecting a Wizard Profile

The following window appears each time the Anybus Configuration Manager is started, or upon selecting the ‘New’ entry in the ‘File’-menu (unless it has been disabled in the ‘Options’-menu, see “Tools” on page 25).

Currently, the following wizards are available:

- **ABCC ExtLink Wizard**  
This wizard is intended for use with the Anybus-CompactCom Modbus-RTU fieldbus communication adapter.
- **Wizard - Modbus RTU Master**  
This option is suitable for Modbus RTU-based networks.  
See also “Wizard - Modbus RTU Master” on page 67.
- **Blank Configuration**  
This option creates an empty configuration.



Highlight the desired wizard and click ‘OK’ to continue.

## 13.3 Wizard - Modbus RTU Master

This wizard can be used to create a Modbus RTU-based network configuration based on certain information about the subnetwork. The online help system explains each configuration step in detail.

- **Important Notes:**

Many OEM devices do not fully comply with the Modbus standard. For example, they may implement a variation of this standard or be limited to the use of specific Modbus commands other than the ones used by this wizard. In all cases, the user should consult the documentation of the devices that shall be used on the subnetwork for information about their serial communication requirements, and if necessary contact the manufacturer of the device to obtain further information about the serial communication protocol.

In the event that the wizard doesn't handle a particular Modbus command required by a device, it is possible to specify this command manually as a transaction in the Anybus Configuration Manager.


Using this wizard involves the following steps:

### Step 1: Communicator Type

Select 'INTERBUS-S'.

Click 'Next' to continue.


**Tip:** It is possible to return to a previous menu at any time without losing any settings by clicking 'Previous'.



### Step 1a: I/O Sizes

Specify the sizes of the input and output data areas. For more information, see "IO Sizes" on page 28.


Click 'Next' to continue.



### Step 2: Physical Settings

Select the physical properties of the subnetwork.

Click 'Next' to continue.



### Steps 3 - 6

Consult the online help system for further information.

## 14. Control and Status Registers

### 14.1 General

The Control and Status Registers are disabled by default, but can be enabled using the Anybus Configuration Manager (see “Status / Control Word” on page 29). These registers form an interface for exchanging status information between the subnetwork and the fieldbus control system.

The main purpose of these registers is to...


- Report subnetwork related problems to the fieldbus control system
- Ensure that only valid data is exchanged in both directions
- Enable the fieldbus control system to start/stop data exchange with selected nodes on the subnetwork

If enabled, these registers occupy the first two bytes in the input and output data areas (0x000-0x001 and 0x200-0x201 respectively), which means they can be accessed from the fieldbus just like any other data in these areas.

**Note:** Internally, these registers are stored in Motorola-format (i.e. MSB first). If the higher level network uses a different byte order, the upper and lower bytes will appear swapped.

#### 14.1.1 Handshaking Procedure

A special handshaking procedure, which is illustrated in the two flowcharts below, must be followed when accessing these registers to ensure that both parts receive proper information.



## 14.1.2 Data Consistency

The 'Data Valid'-bits in the Control and Status Registers are used to ensure data consistency during start-up and fieldbus offline/online transitions.

If the 'Status / Control Word'-parameter in Anybus Configuration Manager is set to 'Enabled', the gateway will wait for the fieldbus control system to set the 'Data Valid'-bit in the Control Register before it starts exchanging data on the subnetwork.

If the same parameter is set to 'Disabled' or 'Enabled but no startup lock', communication will start as soon as the fieldbus goes online.

### State Machine

The fieldbus network participation can be described using a state machine as described below.

#### A: Offline (No data exchange)


1. Clear the 'Data Valid'-bit in the Control Register.
2. Write initial data to the Output Area according to the subnetwork configuration.
3. Wait until the fieldbus control system and the gateway are online on the fieldbus network, and shift to state B.

#### B: Online (Not yet exchanging data)

4. Wait until the 'Data Valid'-bit in the Status Register is cleared by the gateway.
5. Set the 'Data Valid'-bit in the Control Register.
6. When the 'Data Valid'-bit in the Status Register is set by the gateway, shift to state C.
7. If the gateway goes offline on the fieldbus, shift to state A.

#### C: Online (Exchanging data)

Exchanging valid data in both directions.  
If the gateway goes offline on the fieldbus, shift to state A.



**Note:** The gateway cannot spontaneously clear the 'Data Valid'-bit in the Status Register.

### Latency

The 'Data Valid'-bit in the Status Register may in some cases be delayed. This latency can be caused by a missing node or a bad connection to a node with a long timeout value assigned to it.

Therefore, the fieldbus control system should not wait for this bit to be set before communicating with the subnetwork devices; it should be considered as an aid for the fieldbus control system to know when all data has been updated.

## 14.2 Status Register Contents (Gateway to Control System)

### 14.2.1 General Information

The Status Register is (if enabled) located at 0x000-0x001 and constitutes a bit-field as follows:

| bit(s)  | Name  | Description   |
|---------|---|---|
| 15      | Send (SR_HS_SEND)                                 | These bits control the handshaking towards the fieldbus control system.<br><br>See also...<br>- "Handshaking Procedure" on page 68<br>- "Control Register Contents (Control System to Gateway)" on page 72        |
| 14      | Confirm (SR_HS_CONFIRM)                           |   |
| 13      | Data Valid (Master Mode and DF1 Master Mode Only) | This bit is set when all transactions have been executed successfully at least once. Once set, it will not change.<br>1:Data Valid<br>0:Data not Valid<br><b>Note:</b> This bit is not used in Generic Data Mode. |
| 12... 8 | Status Code                                       | This field holds the last status report from the gateway.   |
| 7... 0  | Data  | See also...<br>- "Status Codes in Master Mode and DF1 Master Mode" on page 70<br>- "Status Code in Generic Data Mode" on page 71  |

**Note:** Internally, this is treated as a Motorola-format word (i.e. MSB first). If the higher level network uses a different byte order, the upper and lower bytes will appear swapped.

### 14.2.2 Status Codes in Master Mode and DF1 Master Mode

(This table is valid only in Master Mode and DF1 Master Mode).

| Code | Condition                      | Type    | Data            | Description   |
|------|--------------------------------|---------|-----------------|---|
| 0x00 | Retransmission Counter Updated | Warning | Counter         | The number of retransmissions on the subnetwork has increased. If this problem persists, this may eventually trigger a Single- or Multiple Node(s) Missing condition. |
| 0x01 | Single Node Missing            | Error   | Slave address   | A single node is missing.   |
| 0x02 | Multiple Nodes Missing         | Error   | Number of nodes | Multiple nodes are missing.   |
| 0x03 | Buffer Overrun                 | Warning | Slave address   | A node returned more data than expected.  |
| 0x04 | Other Error                    | Error   | Slave address   | Undefined error   |
| 0x1F | No Error                       | Warning | -               | No errors   |

**Note:** Conditions of type 'Error' will eventually be followed by a 'No Error' condition when the cause has been resolved. Conditions of type 'Warning' are however considered informational and may not necessarily be followed by a 'No Error' condition later on.

### 14.2.3 Status Code in Generic Data Mode

(This table is valid only in Generic Data Mode).

| Code | Condition                           | Type    | Data    | Description  |
|------|-------------------------------------|---------|---------|--|
| 0x00 | Invalid Transaction Counter Updated | Error   | Counter | The number of invalid transactions (i.e. received transactions which doesn't match any of the consume-transactions defined in the subnetwork configuration) has increased. |
| 0x01 | Frame Error                         | Warning | -       | End character is enabled, but a message delimiter timeout occurs prior to receiving it.  |
| 0x02 | Offline Timeout Counter Updated     | Error   | Counter | The of number of timed out consume-transactions has increased.<br><br>See also...<br>- "Consume-Transactions" on page 38 (Offline timeout time)                            |
| 0x03 | Buffer Overrun                      | Warning | -       | A node returned more data than expected - or - the gateway was unable to finish processing a message prior to receiving a new one.   |
| 0x04 | Other Error                         | Error   | -       | Undefined error  |
| 0x1F | No Error                            | Warning | -       | No errors  |

**Note:** Conditions of type 'Error' will eventually be followed by a 'No Error' condition when the cause no longer is detected. Conditions of type 'Warning' are however considered informational and may not necessarily be followed by a 'No Error' condition later on.

## 14.3 Control Register Contents (Control System to Gateway)

### 14.3.1 General Information

The Control Register is (if enabled) located at 0x200-0x201 and constitutes a bit-field as follows:

| bit(s)  | Name                       | Description   |
|---------|----------------------------|---|
| 15      | Confirm<br>(CR_HS_CONFIRM) | These bits control the handshaking towards the gateway.   |
| 14      | Send<br>(CR_HS_SEND)       | See also...<br>- "Handshaking Procedure" on page 68<br>- "Status Register Contents (Gateway to Control System)" on page 70  |
| 13      | Data Valid                 | This bit controls data consistency (see "Data Consistency" on page 69).<br>1:Output Area valid; exchange data on the subnetwork<br>0:Output Area not valid; do not exchange data on the subnetwork<br><b>Note:</b> This bit is only relevant if the Control/Status Registers are set as 'Enabled' |
| 12      | Execute Command            | If set, the specified command will be executed by the gateway (see below).  |
| 11... 8 | Control Code               | This field holds commands which can be executed by the gateway (see below).   |
| 7... 0  | Data                       | See also...<br>- "Control Codes in Master Mode and DF1 Master Mode" on page 72<br>- "Control Codes in Generic Data Mode" on page 72   |

**Note:** Internally, this is treated as a Motorola-format word (i.e. MSB first). If the higher level network uses a different byte order, the upper and lower bytes will appear to be swapped.

### 14.3.2 Control Codes in Master Mode and DF1 Master Mode

(This table is valid only in Master Mode and DF1 Master Mode).

| Code | Instruction  | Data                             | Description   |
|------|--------------|----------------------------------|---|
| 0x00 | Disable Node | Actual node address              | Disables the specified node.  |
| 0x01 | Enable Node  | Actual node address              | Enables a previously disabled node.   |
| 0x02 | Enable Nodes | Actual number of nodes to enable | Enables the specified number of nodes, starting from the first node in the configuration. Remaining nodes will be disabled. |

### 14.3.3 Control Codes in Generic Data Mode

(No Control Codes are currently supported in this mode).



## 15. Advanced Fieldbus Configuration

### 15.1 General


The fieldbus interface of the gateway consists of an embedded Anybus-S communication interface. Normally, the Anybus-S configuration settings are set up automatically by the gateway. However, advanced users can configure the Anybus-S card for specific features. This chapter assumes that the reader is familiar with the Anybus-S and its application interface. For more information about the Anybus-S platform, consult the Anybus-S Parallel Design Guide.

The standard initialization parameters are determined by the subnetwork configuration. Information about the amount of input and output data used for subnetwork communication is used by Anybus Configuration Manager to create the configuration message that sets the sizes of the input and output data areas in the Dual Port RAM of the embedded Anybus-S interface. It is possible to add fieldbus specific mailbox messages to customize the initialization. This is done in the Mailbox Editor, see below.

(A mailbox message is a HMS specific command structure used for low-level communication with an Anybus-S interface. Consult the Anybus-S Parallel Design Guide and the fieldbus appendix for the desired fieldbus for further information.)

### 15.2 Mailbox Editor


To add a mailbox message to the configuration, right-click on 'EndInit' and select 'Insert New Mailbox'.



A mailbox message consists of a Header section and a data section where the Header consists of 16 words (32 bytes) and the data section consists of up to 128 words (256 bytes). All fields are editable except the Message information field that is fixed to 0x4002, which means that only fieldbus specific mailbox messages can be entered here.

The mailbox message is presented as two columns; one contains header information (A), the other one contains the message data (B).

To add message data, simply change the Data size parameter in the header column (A), and the corresponding number of bytes will appear in the message data column (B).



For more information about fieldbus specific mailbox messages, consult the separate Anybus-S Fieldbus Appendix for the fieldbus you are using. For general information about the Anybus-S platform, consult the Anybus-S Design Guide.

## A. PCP Bandwidth Configuration


### A.1 General

By default, the Anybus Communicator uses 1 word for PCP-transmission. It is possible to specify a different PCP bandwidth by adding the appropriate mailbox message to the configuration.


This is achieved using the Mailbox Editor in the Anybus Configuration Manager. For more information about the Mailbox Editor, see “Advanced Fieldbus Configuration” on page 73.

### A.2 Add a Mailbox Message

To add a mailbox message to the configuration, right-click on ‘EndInit’ and select ‘Insert New Mailbox’.



This causes the following window to appear:



This window, a.k.a. the Mailbox Editor, will be used in the examples later in this chapter.

See also “Mailbox Editor” on page 73.

## A.3 Specifying the PCP Bandwidth

To specify the PCP bandwidth, perform the following steps:

1. Add a new mailbox message to the configuration (see “Add a Mailbox Message” on page 74).
2. Change the ‘Command’-value in the mailbox header (left column) to 0001h.
3. Change the ‘Data Size’-value in the mailbox header (left column) to 0001h.
4. Specify the desired number of PCP words in Message Data Byte 1.

| Value   | Meaning                           |
|---------|-----------------------------------|
| 00h     | Disable PCP transmission.         |
| 01h     | Use 1 word for PCP transmission.  |
| 02h     | Use 2 words for PCP transmission. |
| 04h     | Use 4 words for PCP transmission. |
| (other) | (invalid setting)                 |


**Note:** PCP effectively reduces the number of words available for cyclic I/O. Make sure that the number of words used for PCP transmission is compatible with the actual I/O configuration. It is not possible to specify 0 (zero) words of PCP in combination with parameter data.

5. To save the new mailbox, select ‘Apply changes’ in the ‘File’-menu.

## B. Connector Pin Assignments


### B.1 Bus-in Connector (INTERBUS)

| Pin     | Signal | Description              |
|---------|--------|--------------------------|
| Housing | Shield | Cable Shield             |
| 1       | DO1    | Non-inverted Data Output |
| 2       | DI1    | Non-inverted Data Input  |
| 3       | GND    | Signal Ground            |
| 4       | NC     | Not Connected            |
| 5       | NC     | Not Connected            |
| 6       | /DO1   | Inverted Data Output     |
| 7       | /DI1   | Inverted Data Input      |
| 8       | NC     | Not Connected            |
| 9       | NC     | Not Connected            |



### B.2 Bus-out Connector (INTERBUS)

| Pin     | Signal | Description              |
|---------|--------|--------------------------|
| Housing | Shield | Cable Shield             |
| 1       | DO2    | Non-inverted Data Output |
| 2       | DI2    | Non-inverted Data Input  |
| 3       | GND    | Signal Ground            |
| 4       | NC     | Not Connected            |
| 5       | NC     | Not Connected            |
| 6       | /DO2   | Inverted Data Output     |
| 7       | /DI2   | Inverted Data Input      |
| 8       | NC     | Not Connected            |
| 9       | NC     | Not Connected            |



### B.3 Power Connector

| Pin | Description |
|-----|-------------|
| 1   | +24V DC     |
| 2   | GND         |




**Notes:**

- Use 60/75 or 75×C copper (CU) wire only.
- The terminal tightening torque must be between 5... 7 lbs-in (0.5... 0.8 Nm)


## B.4 PC Connector

### Configuration Cable Wiring




### RJ11 (4P4C modular)<sup>1</sup> : ABC

| Pin | Description       |
|-----|-------------------|
| 1   | Signal ground     |
| 2   |                   |
| 3   | RS232 Rx (Input)  |
| 4   | RS232 Tx (Output) |



### DB9F : PC

| Pin   | Description       |
|-------|-------------------|
| 1     | -                 |
| 2     | RS232 Rx (Input)  |
| 3     | RS232 Tx (Output) |
| 4     | -                 |
| 5     | Signal Ground     |
| 6 - 9 | -                 |



1. The RJ11 (4P4C modular) is sometimes referred to as an RJ9.

## B.5 Subnetwork Interface

### B.5.1 General Information

The subnetwork interface provides for RS232, RS422 and RS485 communications. Depending on the configuration specified in the Anybus Configuration Manager, different signals are activated in the subnetwork connector.



### B.5.2 Bias Resistors (RS485 Only)

When idle, RS485 enters an indeterminate state, which may cause the serial receivers to pick up noise from the serial lines and interpret this as data. To prevent this, the serial lines should be forced into a known state using pull-up and pull-down resistors, commonly known as bias resistors.

The bias resistors form a voltage divider, forcing the voltage between the differential pair to be higher than the threshold for the serial receivers, typically >200mV.

Note that bias resistors shall only be installed on one node; installing bias resistors on several nodes may compromise the signal quality on the network and cause transmission problems.


### B.5.3 Termination (RS485 & RS422 Only)

To avoid reflections on the serial lines, it is important to properly terminate the subnetwork by placing termination resistors between the serial receivers near the end nodes.

The resistor value should ideally match the characteristic impedance of the cable, typically 100... 120R.


### B.5.4 Connector Pinout (DB9F)

| Pin       | Description                | RS232 | RS422 | RS485 |
|-----------|----------------------------|-------|-------|-------|
| 1         | +5V Output(100mA max)      | ✓     | ✓     | ✓     |
| 2         | RS232 Rx                   | ✓     |       |       |
| 3         | RS232 Tx                   | ✓     |       |       |
| 4         | (reserved)                 |       |       |       |
| 5         | Signal Ground <sup>a</sup> | ✓     | ✓     | ✓     |
| 6         | RS422 Rx +                 |       | ✓     |       |
| 7         | RS422 Rx -                 |       | ✓     |       |
| 8         | RS485 + /RS422 Tx+         |       | ✓     | ✓     |
| 9         | RS485 - /RS422 Tx-         |       | ✓     | ✓     |
| (housing) | Cable Shield               | ✓     | ✓     | ✓     |




a. Connecting this signal directly to Protective Earth (PE) of other nodes may, in case of grounding loops etc., cause damage to the on-board serial transceivers. It is therefore generally recommended to connect it only to Signal Ground (if available) of other nodes.

### B.5.5 Typical Connection (RS485)




### B.5.6 Typical Connection (RS422 & 4-Wire RS485)



**Note:** Bias resistors are normally not needed on RS422, but may be required when using 4-wire RS485.

### B.5.7 Typical Connection (RS232)



## **C. Technical Specification**

### **C.1 Mechanical Properties**

#### **Housing**

Plastic housing with snap-on connection to DIN-rail, protection class IP20

#### **Dimensions**

120 mm x 75 mm x 27 mm, L x W x H (inches: 4.72" x 2.95" x 1.06"; L x W x H)

### **C.2 Electrical Characteristics**

#### **Power Supply**

Power: 24V  $\pm$  10%

#### **Power Consumption**

Maximum power consumption is 280mA on 24V. Typically around 100mA

### **C.3 Environmental Characteristics**

#### **Relative Humidity**

The product is designed for a relative humidity of 0 to 95% non-condensing

#### **Temperature**

Operating:  $\pm$ 0°C to +55°C

Non Operating: -25°C to +85°C



## C.4 Regulatory Compliance

### EMC Compliance (CE)

This product is in accordance with the EMC directive 89/336/EEC, with amendments 92/31/EEC and 93/68/EEC through conformance with the following standards:

- **EN 50082-2 (1993)**  
EN 55011 (1990) Class A
  
- **EN 61000-6-2 (1999)**  
EN 61000-4-3 (1996) 10V/m  
EN 61000-4-6 (1996) 10V/m (all ports)  
EN 61000-4-2 (1995)  $\pm 8$ kV Air Discharge  
 $\pm 4$ kV Contact discharge  
EN 61000-4-4 (1995)  $\pm 2$ kV Power port  
 $\pm 1$ kV Other ports  
EN 61000-4-5 (1995)  $\pm 0.5$ kV Power ports (DM/CM)  
 $\pm 1$ kV Signal ports

### UL/c-UL compliance

The certification has been documented by UL in file E214107.

### Galvanic isolation on subnetwork interface

- **EN 60950-1 (2001)**  
Pollution Degree 2  
Material Group IIIb  
250 V<sub>RMS</sub> or 250 VDC Working voltage  
500 V Secondary circuit transient rating

## D. Troubleshooting

| Problem   | Solution  |
|---|---|
| Problem during configuration Upload / Download.<br>The Config Line "LED" turns red in the Anybus Configuration Manager. | <ul style="list-style-type: none"> <li>Serial communication failed. Try again</li> </ul>  |
| The serial port seems to be available, but it is not possible to connect to the gateway                                 | <ul style="list-style-type: none"> <li>The serial port may be in use by another application. Exit the Anybus Configuration Manager and close all other applications including the ones in the system tray.<br/>Try again</li> <li>Select another serial port<br/>Try again</li> </ul>   |
| Poor performance  | <ul style="list-style-type: none"> <li>Right click 'subnetwork' in the Navigation window and select 'subnetwork Status' to see status / diagnostic information about the subnetwork.<br/>If the gateway reports very many retransmissions, check your cabling and/or try a lower baud rate setting for the subnetwork (if possible).</li> <li>Is the Subnet Monitor in the Anybus Configuration Manager active?<br/>The subnetwork monitor has a negative influence on the overall performance of the gateway, and should only be used when necessary.</li> <li>Is the Node Monitor in the Anybus Configuration Manager active?<br/>The node monitor has a negative influence on the overall performance of the gateway, and should only be used when necessary.</li> </ul> |
| No subnetwork functionality   | <ul style="list-style-type: none"> <li>Use the 'Data logger'-functionality to record the serial data communication on the subnetwork.</li> <li>If no data is being transmitted, check the configuration in Anybus Configuration Manager.</li> <li>If no data is received, check the subnetwork cables. Also verify that the transmitted data is correct.</li> </ul>   |

## E. ASCII Table

|    | x0         | x1        | x2        | x3        | x4        | x5        | x6        | x7        | x8        | x9       | xA        | xB        | xC       | xD       | xE       | xF         |
|----|------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|----------|-----------|-----------|----------|----------|----------|------------|
| 0x | NUL<br>0   | SOH<br>1  | STX<br>2  | ETX<br>3  | EOT<br>4  | ENQ<br>5  | ACK<br>6  | BEL<br>7  | BS<br>8   | HT<br>9  | LF<br>10  | VT<br>11  | FF<br>12 | CR<br>13 | SO<br>14 | SI<br>15   |
| 1x | DLE<br>16  | DC1<br>17 | DC2<br>18 | DC3<br>19 | DC4<br>20 | NAK<br>21 | SYN<br>22 | ETB<br>23 | CAN<br>24 | EM<br>25 | SUB<br>26 | ESC<br>27 | FS<br>28 | GS<br>29 | RS<br>30 | US<br>31   |
| 2x | (sp)<br>32 | !<br>33   | "<br>34   | #<br>35   | \$<br>36  | %<br>37   | &<br>38   | '<br>39   | (<br>40   | )<br>41  | *<br>42   | +<br>43   | ,<br>44  | -<br>45  | .<br>46  | /<br>47    |
| 3x | 0<br>48    | 1<br>49   | 2<br>50   | 3<br>51   | 4<br>52   | 5<br>53   | 6<br>54   | 7<br>55   | 8<br>56   | 9<br>57  | :<br>58   | ;<br>59   | <<br>60  | =<br>61  | ><br>62  | ?<br>63    |
| 4x | @<br>64    | A<br>65   | B<br>66   | C<br>67   | D<br>68   | E<br>69   | F<br>70   | G<br>71   | H<br>72   | I<br>73  | J<br>74   | K<br>75   | L<br>76  | M<br>77  | N<br>78  | O<br>79    |
| 5x | P<br>80    | Q<br>81   | R<br>82   | S<br>83   | T<br>84   | U<br>85   | V<br>86   | W<br>87   | X<br>88   | Y<br>89  | Z<br>90   | [<br>91   | \<br>92  | ]<br>93  | ^<br>94  | _<br>95    |
| 6x | `<br>96    | a<br>97   | b<br>98   | c<br>99   | d<br>100  | e<br>101  | f<br>102  | g<br>103  | h<br>104  | i<br>105 | j<br>106  | k<br>107  | l<br>108 | m<br>109 | n<br>110 | o<br>111   |
| 7x | p<br>112   | q<br>113  | r<br>114  | s<br>115  | t<br>116  | u<br>117  | v<br>118  | w<br>119  | x<br>120  | y<br>121 | z<br>122  | {<br>123  | <br>124  | }<br>125 | ~<br>126 | DEL<br>127 |